## **SAFETY PRECAUTIONS**



Avoid exposing the fuel gasses to any potential sources of ignition as the resulting fire and explosion may cause serious injuries and/or death.



Switch off the engine when refuelling, as it is both a source of extreme temperatures, and electrical sparks.



Switch off any personal electronic devices such as mobile phones or music players.

### PETROL ENGINED VEHICLES



Do not use leaded fuels, lead substitutes, or fuel additives.



Fuel system cleaning agents should not be used, unless approved by Land Rover.

### **OCTANE RATING**

The minimum octane rating for fuel used is 95 RON. The vehicle will run on lower ratings, but it may cause pronounced engine knock or pinking. If the pinking is severe it can cause damage to the engine, fuel and emission control systems.

**Note:** Occasional, light, engine knock experienced while accelerating or climbing hills is acceptable.

## **ETHANOL**



This vehicle is not suitable for use with fuels containing more than 10% Ethanol.

①

Do not use E85 fuels (85% Ethanol content). Equipment necessary for the use of fuels containing more than 10% Ethanol is not fitted to this vehicle. If E85 fuels are used, serious engine and fuel system damage will occur.

Fuels containing up to 10% Ethanol (grain alcohol) may be used. Ensure that the fuel has octane ratings no lower than those recommended for unleaded fuel. Most drivers will not notice any operating difference with fuel containing Ethanol. If a difference is detected, the use of conventional unleaded fuel should be resumed.

### **METHANOL**



Wherever possible avoid using fuel containing methanol.

Some fuels contain methanol (Methyl or wood alcohol). If you use fuels containing methanol the fuels must also contain co-solvents and corrosion inhibitors for methanol. Also, do not use fuels which contain more than 3% methanol even if they contain co-solvents and corrosion inhibitors. Fuel system damage or vehicle performance problems resulting from the use of such fuels is not the responsibility of Land Rover, and may not be covered under the warranty.

# METHYL TERTIARY BUTYL ETHER (MTBE)

Unleaded fuel containing an oxygenate known as MTBE can be used provided that the ratio of MTBE to conventional fuel does not exceed 15%. MTBE is an Ether based compound derived from Petroleum, which has been specified by several refiners as the substance to enhance the Octane rating of fuel.

## REFORMULATED GASOLINE

Several petroleum companies have announced the availability of reformulated fuels. These fuels are specially formulated to further reduce vehicle emissions. Land Rover fully supports all efforts to protect and maintain ambient air quality, and encourages the use of reformulated gasoline where available.

### DIESEL ENGINED VEHICLES

Land Rover recommends that only premium brand diesel fuels are used.

**Note:** Land Rover vehicles are capable of running with up to a 7% blend of bio-diesel in accordance with European Standard EN590.

### SULPHUR CONTENT



If your vehicle is fitted with a Diesel Particulate Filter (DPF) the maximum Sulphur content must not exceed 0.005%. Using an incorrect fuel will cause serious damage to the DPF.

The Sulphur content of diesel used in Land Rover vehicles should not exceed 0.3% (3000 parts per million).

In some countries diesel will contain higher levels of Sulphur, which will require reduced service intervals to reduce the effects on engine components. If in doubt contact a local Land Rover Dealer/Authorised Repairer for advice.

### **RUNNING OUT OF FUEL**



Avoid running out of fuel. Doing so can cause damage to the vehicle's engine, fuel, and emission control systems.

If the vehicle does run out of fuel, a minimum of 4 litres (0.8 gallons) will be required to restart the engine. The vehicle will need to be driven 1.6-5 km (1-3 miles) in order to reset the engine management and monitoring systems.


#### Note:

If the vehicle does run out of fuel, seeking qualified assistance is advisable.

### **FUEL FILLER FLAP**



Take note of all warnings and instructions given on the label affixed to the inside of the filler flap.



The fuel filler flap is located on the right-hand side of the vehicle, at the rear.

1. Ensure that the vehicle is fully unlocked, and press the left side of the flap to open.

- 2. Open the flap fully and twist the cap anticlockwise to undo.
- 3. Use the retaining clip to keep the filler cap out of the way whilst fuelling.

### **FUEL FILLER**



When refuelling ensure that all windows, doors, and sunroof are fully closed, particularly if young children or animals are in the vehicle.



Do not attempt to fill the tank to its maximum capacity. If the vehicle is to be parked on a slope, in direct sunlight, or high ambient temperature, expansion of the fuel could cause spillage.



Do not operate the auxiliary heater when refuelling the vehicle. Doing so may cause fuel vapours to combust causing a fire/explosion.



Check the fuel pump information carefully, to ensure that you are putting the correct fuel into the vehicle.



If the vehicle is filled with incorrect fuel it is essential that you seek qualified assistance before you start the engine.

Filling station pumps are equipped with automatic cut-off sensing to avoid fuel spillage. Fill the tank until the filler nozzle automatically cuts-off the supply. Do not attempt to fill the tank beyond this point.

Note: Filling station pumps used for diesel commercial vehicles deliver fuel at a higher rate than normal. The higher fill rate can cause premature cut-off and may cause fuel spillage. Therefore, it is recommended that only standard light vehicle pumps are used.

# DIESEL MISFUEL PROTECTION DEVICE



When the misfuelling device is activated, it may cause fuel to be discharged from the filler neck.

**Note:** It is the driver's responsibility to fill the vehicle with the correct fuel. The diesel misfuel protection device only reduces the risk of filling the vehicle with the incorrect fuel.


Diesel engine vehicles in some markets are equipped with a misfuelling protection device, incorporated into the fuel filler neck.

If the narrow filler nozzle fitted to pumps delivering unleaded petrol is fully inserted into the filler neck, the misfuel protection device will activate.

**Note:** The filler spout on some fuel cans and older fuel pumps may trigger the misfuelling device.

When activated, the yellow misfuel protector will be visible inside the filler neck. It will prevent fuel flow into the tank. Before fuelling can continue with the correct fuel, the device will need to be reset.

The reset tool is located in the luggage compartment.



Reset the misfuel protection device as follows:

- Insert the reset tool (with the teeth uppermost) as far as it will go into the filler neck.
- 2. Locate the teeth by pushing down the top of the reset tool.
- With the top of the tool pressed down and the teeth engaged, slowly pull the tool out of the filler neck to reset the device.
- ① Do not twist the device, once the teeth have engaged.

**Note:** The yellow part of the protection device should no longer be visible in the filler neck.

Return the reset tool to the luggage compartment.

### **FUEL TANK CAPACITY**

Avoid the risk of running out of fuel and never intentionally drive the vehicle when the fuel gauge indicates that the tank is empty. When refuelling your vehicle after the fuel gauge reads empty, you may not be able to add the fuel quantity shown below, as there will be a small reserve remaining in the tank.

Total tank capacity (usable):	
Petrol engines	70 litres
	(15.4 gallons)
Diesel engines	68 litres
	(15 gallons)

### **FUEL SPECIFICATION**

Petrol	Diesel	
91-98 RON	EN 590	

①

Diesel vehicles in Algeria, Egypt, Libya, Morocco, India, Pakistan and Tunisia must only use premium diesel fuel.

### **FUEL CONSUMPTION**

The fuel consumption figures shown below have been calculated using a standard testing procedure (the new EC test procedure from Directive 99/100/EC) and produced in accordance with The Passenger Car Fuel Consumption (Amendment) Order 1996.

Under normal use, a vehicle's actual fuel consumption figures may differ from those achieved through the test procedure, depending on driving technique, road and traffic conditions, environmental factors, vehicle load and condition.

Variant	Urban	Extra-urban	Combined	CO2 emissions
	I/100 km (mpg)	l/100 km (mpg)	I/100 km (mpg)	g/km
Diesel (manual)	7.4 (38.2)	5.6 (50.4)	6.2 (45.6)	165
Diesel (automatic)	8.7 (32.5)	5.7 (49.6)	7.0 (40.4)	185
Petrol	15.5 (18.2)	8.1 (34.9)	10.7 (26.4)	255

### **URBAN CYCLE**

The urban test cycle is carried out from a cold start and consists of a series of accelerations, decelerations and periods of steady speed driving and engine idling. The maximum speed attained during the test is 50 km/h (30 mph) with an average speed of 19 km/h (12 mph).

For additional information on fuel consumption figures and exhaust emissions, visit the Vehicle Certification Agency (VCA) website at <a href="http://www.vcacarfueldata.org.uk/">http://www.vcacarfueldata.org.uk/</a>.



#### **EXTRA-URBAN CYCLE**

The extra-urban test cycle is carried out immediately after the urban test. Approximately half of the test comprises steady speed driving, while the remainder consists of a series of accelerations, decelerations and engine idling. The maximum test speed is 120 km/h (75 mph) and the average speed 63 km/h (39 mph). The test is carried out over a distance of 7 km (4.3 miles).

### COMBINED

The combined figure is an average of the urban and extra-urban test cycle results, which has been weighted to take account of the different distances covered during the two tests.