

## WHEEL CHANGING


1. Loosen the wheel nuts half a turn (counterclockwise).
2. Position the jack at the relevant jacking point.
3. Raise the vehicle with a slow steady operation. Avoid rapid, jerky actions as they may cause the vehicle/jack to become unstable.
4. Remove the wheel nuts and place them together where they cannot roll away.
5. Remove the wheel and place to one side. Do not lay the wheel on it's face, as this may damage the finish.
6. Fit the spare wheel to the hub.
7. Re-fit the wheel nuts, and lightly tighten them. Ensure that the wheel is making contact with the hub evenly.
8. Ensure that the space under the vehicle is clear of obstructions, and lower the vehicle slowly and smoothly.
9. With all wheels on the ground and the jack removed, fully tighten the wheel nuts. The wheel nuts must be tightened in sequence to the correct torque. **5.5 inch steel wheels**, 108 Nm (80 lb.ft). **6.5 inch steel wheels**, 170 Nm (125 lb.ft). **7 inch alloy wheels**, 170 Nm (125 lb.ft).

**Note:** If it is not possible to torque the wheel nuts when a wheel is replaced, they should be set to the correct torque as soon as possible.

10. If an alloy spare wheel is to be fitted, using a suitable blunt tool, knock the centre cap out of the removed wheel. Using hand pressure only, press the centre cap into the newly fitted spare.
11. Check and adjust the tyre pressure as soon as possible.
12. Return the jack, tools, chocks, and removed wheel to their correct storage positions.



**Do not use the spare wheel securing nuts in place of the road wheel nuts, or use the road wheel nuts in place of the spare wheels nuts. They are not interchangeable.**



E132675