

INTELLIGENT STOP/START

The Stop/Start system is designed to improve fuel efficiency and is automatically activated when the ignition is turned on. If the vehicle is stopped (e.g. at traffic lights or in traffic) the engine will turn off (unless it is required to support other vehicle systems). When the brake is released and a drive gear is selected, the engine will restart automatically.



The warning lamp in the instrument panel illuminates when the engine has been switched off by the Stop/Start system.

To activate an automatic engine stop:

- Stop the vehicle from a speed greater than 4 km/h (2.5 mph) and apply sufficient brake pressure to ensure the vehicle is stationary.
- Alternatively, whilst stationary, select Neutral (**N**).

To activate an automatic engine restart release the brake pedal with Drive (**D**) or Sport (**S**) selected.

The engine will also restart if one of the following occurs:

- Stop/Start is deactivated.
- The accelerator pedal is pressed.
- Reverse (**R**) is selected.
- Climate control system demand increases.
- The vehicle's speed exceeds approximately 1 km/h (0.5 mph).
- Battery charge becomes low.
- Brake vacuum has been reduced (e.g. using the brake pedal repeatedly with the engine off).

The following conditions will prevent an automatic engine stop:

- The external temperature is less than approximately 0 °C (32 °F).
- The external temperature is more than approximately 40 °C (104 °F).
- The engine has not reached operating temperature.
- The driver's seat belt is not fastened.
- The climate control system demand requires the engine to be running (for example, in Defrost mode).
- The battery charge is low.
- The bonnet is opened.
- Stop/Start is deactivated.

DEACTIVATING INTELLIGENT STOP/START

To switch the system off, press the **ECO** switch.

***Note:** The engine will restart automatically if the switch is pressed whilst an automatic engine stop is in progress.*



To confirm that the system is off, the Intelligent stop/start system off warning symbol illuminates and the message **ECO Stop/Start Off** is momentarily displayed.

The Intelligent stop/start system off warning symbol also illuminates if there is a system fault. If the **ECO** switch is pressed while there is a fault, the message **ECO Stop/Start Unavailable** is displayed.