Starting the engine

To switch on the ignition without starting the engine.

- Ensure the brake pedal is not depressed and that a valid Smart Key is inside the vehicle
- 2. Press and hold the engine **START/STOP** button until the warning lamps illuminate.
- 3. Release the engine START/STOP button.
- If the brake pedal is applied when the engine **START/STOP** button is pressed, the engine will start.

ROLLING RE-START

A rolling restart can be initiated by selecting Neutral (N) and pressing the engine **START/STOP** button.

KEYLESS START BACKUP

If the vehicle has been unlocked using the emergency key blade or the Smart Key is not detected by the vehicle, it will be necessary to use the keyless start backup to disarm the alarm and start the engine.

The keyless start backup can only be used when the message **Smart Key Not Found** - **Refer to Handbook** is displayed in the Driver information centre.



- Position the Smart Key against the underside of the steering column cover with the buttons facing downwards.
- 2. Firmly depress the brake pedal.
- 3. Press and release the engine **START/STOP** button.

Once the engine has started, the brake pedal can be released if it is safe to do so.

If the Smart Key is not recognised, or the engine still fails to start, consult a Land Rover Dealer/Authorised Repairer.