Gearbox

RANGE CHANGING ON THE MOVE

The recommended method of changing range is with the vehicle stationary. For experienced off-road drivers, a range change on-the-move can be accomplished, as detailed below.

AUTOMATIC TRANSMISSION HIGH TO LOW RANGE

- With the vehicle slowing down, and travelling between 40 km/h (24mph) and 3 km/h (2 mph), select N.
- 2. Press the rear of the transfer gear switch to select **Lo**.
- Wait for the range change to be completed (this may take several seconds). Once complete, select the desired gear. A gear cannot be selected until the range change is complete.

CHANGING FROM LOW TO HIGH RANGE

With the vehicle travelling no faster than 60 km/h (38 mph), select $\bf N$ or neutral. Press the front of the transfer gear switch to the $\bf Hi$ position and release it.

Indication of the range change status is the same as for the stationary method.

Now select **D**.