Heating and ventilation

11. Rear environment:

- Press once to control the rear heating and air conditioning using the front controls only. The lower amber lamp is illuminated
- Press a second time to allow the rear passengers to have manual control.
 The upper amber light is illuminated.
 See 61. REAR CLIMATE CONTROL.
- · Press a third time to switch off.

Note: The indicator lights in the switches will illuminate when the function is selected.

Note: In low temperatures it is advisable to close the centre face level vent and direct air flow from the outer face level vents towards the side windows. This will help to keep the windows clear of ice.

AUTOMATIC CLIMATE CONTROL

Press **AUTO** to select automatic operation.

The system will adjust the heat output, blower speed, air intake and airflow distribution to maintain the selected temperature(s) and reduce misting without further adjustments.

The air distribution and blower controls may be operated independently to override Auto mode. If you do this, the indicator lamp on the AUTO switch will go out. Press **AUTO** again to return to automatic operation.

Note: The system will not achieve a temperature differential from left to right of more than 4°C (7°F).

AUTOMATIC RECIRCULATION

If an air quality sensor is fitted, the climate control system will monitor exterior air pollution and humidity and select recirculation if either reaches a predetermined level. This feature only operates when the climate control system is in AUTO mode. The sensitivity of the air quality sensor can be set via the touch screen.

Pressing the recirculation button will deactivate automatic recirculation.

AIR QUALITY SENSOR

The sensitivity of the air quality sensor can be adjusted using the touch screen:

- 1. Select Settings from the Climate menu.
- Touch the +/- buttons on the screen to increase/decrease sensitivity.

To switch off air quality sensing, decrease sensitivity to the minimum setting.



The auto recirculation icon appears on the touch screen when the air quality sensor is switched on.

HEATED SCREENS



Heated windscreen.



Heated rear screen.

Press button to operate the required screen heater. The screen heater(s) will operate for a predetermined timed period before automatically switching off.