Heating and ventilation

The heating program will continue for 30 minutes, when it will switch off automatically to prevent the vehicle battery from discharging. It also turns off automatically if the engine is started.

The LED indicator signals various states and conditions for the heater as follows:

- Illuminates green for 2 seconds when the ON button is pressed, to indicate that heater operation has been requested.
- Illuminates red for 2 seconds when the OFF button is pressed, to indicate that the heater has stopped.
- Flashes green or red for 2 seconds when the ON or OFF buttons are pressed, to indicate that the signal was not received.
- Illuminates orange for 2 seconds before showing green or red, to indicate that the remote battery is low.
- Flashes orange for 5 seconds to indicate that the signal was not received and the remote battery should be replaced.

ADDITIONAL REMOTES

Additional remote controls can be programmed to operate the heater. A maximum of 3 remotes can be programmed to each vehicle. Contact a Land Rover Dealer/Authorised Repairer to purchase additional remotes and have them programmed to the vehicle.

REPLACING THE REMOTE BATTERIES



With the back of the remote control facing upwards, use a coin or similar implement to rotate the battery cover. Lift the cover off to reveal the battery compartment. Remove the old battery and, ensuring that the correct polarity is maintained, insert a replacement 3.3 volt, CR1/3N battery. Replace the cover and rotate it to lock closed.