

Note: The locking tabs (3) can be levered too far up, preventing the headlamp from being released. If this happens, ease the tabs down until the headlamp can be moved forward.


5. Disconnect the electrical connector from the back of the unit and remove the unit from the vehicle.

Note: Place face down on a flat surface covered in a soft material, to prevent damage to the units lenses.

6. To access the turn signal, the headlamp unit's locking slide assembly must be completely removed from the unit.
To remove the slide assembly, remove the four screws (arrowed). When refitting the slide, do not overtighten the screws.

Note: Refitting the headlamp unit is the reverse of removal.

HEADLAMP BULB IDENTIFICATION



- A. Xenon bulb.
- B. Halogen bulb.

HALOGEN BULBS

Take care not to touch the glass part of the bulb with your fingers; always use a cloth to handle the bulb. If necessary, use methylated spirits to remove finger prints.

XENON LAMPS

⚠ WARNING

High voltage is required to ignite the gas and metal vapor, which are used to power xenon lamps. Contact with this voltage can cause serious injury. Replacement or maintenance of xenon lamps should only be carried out by suitably qualified personnel.

⚠ WARNING

Xenon lamp units operate at a very high temperature. Make sure that the lamp units have cooled before attempting to touch them.

⚠ WARNING

Xenon lamp units contain mercury, which is highly toxic and can be extremely harmful.



Seek advice about the correct disposal of xenon lamp units from a Retailer/Authorized Repairer, or your local authority.