

11. Disconnect the positive (Red) jump lead from the previously disabled vehicle.
12. Disconnect the positive (Red) jump lead from the donor vehicle.

CONNECTING A STARTING AID

To start the vehicle using a starting aid or a booster battery, follow the instructions in the sequence given:

1. Connect the positive (Red) jump lead to the positive battery terminal of the disabled vehicle.
2. Connect the negative (Black) jump lead to the ground (-) terminal of the battery.
3. Start the engine and allow it to idle.
4. Disconnect the negative (Black) jump lead from the battery terminal of the vehicle.
5. Disconnect the positive (Red) jump lead from the battery terminal of the vehicle.

REMOVING THE VEHICLE BATTERY

WARNING

Switch the ignition off before disconnecting battery terminals.

WARNING

Always disconnect the negative terminal first and reconnect last.

WARNING

Use caution when lifting the battery out of, or into, the vehicle. It is heavy, and may cause injury when lifting, or if dropped.

WARNING

Do not tip the battery when lifting or moving as tilting the battery more than 45 degrees may damage the battery, and may cause the battery fluid to leak out. Battery fluid is highly corrosive, and toxic.

NOTICE

Do not rest the battery on any part of the vehicle, as it may cause damage due to its weight.

NOTICE

Do not run the engine with the battery disconnected. Doing so may damage the charging system.

1. Make sure that all electrical circuits are switched off, all of the windows are closed, and the alarm is disarmed.
2. Remove the Smart key from the vehicle and wait 2 minutes to allow the systems to power down fully.
3. Undo the negative clamp, and lift the cable and clamp clear of the battery terminal.
4. Undo the positive clamp, and lift the cable and clamp clear of the battery terminal.
5. Undo the battery clamp and lift the battery clear of the vehicle.

EFFECTS OF DISCONNECTING

Disconnecting the battery can affect a number of vehicle systems, especially if there is insufficient battery power prior to disconnection. For example, the alarm may trigger depending on its state when the battery was disconnected. If the alarm does sound, use the Smart key in the normal way to disarm the security system. The windows may need recalibrating to operate correctly.