

DEACTIVATING THE ALARM WHEN TRIGGERED

If the alarm has been triggered it can be deactivated by pressing the Smart key unlock button, or by positioning the Smart key underneath the steering column (see **90, IF THE ENGINE FAILS TO START**).