

9. Inflate the tyre to a minimum of 1.8 bar (26 psi, 180 kPa) and a maximum of 3.5 bar (51 psi, 350 kPa).

Note: When pumping the sealant through the tyre valve, the pressure may rise up to 6 bar (87 psi, 600 kPa). The pressure will drop again after approximately 30 seconds.

10. During the inflation, switch the compressor off briefly, to check the tyre pressure using the gauge mounted on the compressor.

Note: It should not take longer than 10 minutes to inflate the tyre. If, after a maximum of 10 minutes, the tyre has not yet reached minimum pressure, the tyre should not be used.

11. Once the tyre has been inflated to the required pressure, switch off the compressor. If desired, the ignition may be turned off after the compressor has been turned off.
12. Remove the power connector from the auxiliary power socket.
13. Remove the inflation hose from the tyre valve, by unscrewing it as quickly as possible in an counter clockwise direction.
14. Replace the inflation hose protective cap and the tyre valve cap.
15. Make sure the tyre repair kit (including the bottle and receiver caps) is placed securely in the vehicle. You will need to use the kit to check the tyre pressure after a maximum of 10 km (6 miles), so make sure it is easily accessible.
16. Immediately drive the vehicle for a maximum of 10 km (6 miles). This will allow the sealant to coat the inner surface of the tyre and form a seal at the puncture.

CHECKING THE TYRE PRESSURE AFTER A REPAIR



When driving the vehicle, if you experience vibrations, abnormal steering, or noises, reduce speed immediately. Drive with extreme caution and reduced speed, to the first safe place to stop the vehicle. Visually examine the tyre and check its pressure. If there are any signs of damage or deformity to the tyre, or the tyre pressure is below 1.3 bar (19 psi, 130 kPa), do not continue driving.



Consult a tyre repair centre or your Dealer/Authorised Repairer, for advice concerning the renewal of a tyre after using a tyre repair kit.

1. Drive the vehicle for a maximum of 10 km (6 miles) then stop in a safe place. Carry out a visual examination of the tyre's condition.
2. Remove the repair kit from the vehicle.
3. Screw the inflation hose connector firmly onto the tyre valve.
4. Read the tyre pressure from the gauge.
5. If the pressure of the sealant filled tyre is above 1.3 bar (19 psi, 130 kPa) adjust the pressure to the correct value.
6. Make sure that the compressor switch is in the off (O) position and insert the power cable connector into the auxiliary power socket. Switch on the ignition. Alternatively, if the vehicle is not in a confined space the engine can be started.
7. Switch the compressor to on (I) and inflate the tyre to the correct pressure. See 240, TYRE PRESSURES.

Tyre repair kit

8. To check the tyre pressure, turn off the compressor and then read the pressure from the gauge.
9. When the compressor is off, if the tyre pressure is too high, release the required amount of pressure using the pressure release valve.
10. Once the tyre is inflated to the correct pressure, switch off the compressor and remove the power plug from the auxiliary socket.
 - The use of the tyre repair kit sealant may lead to error prompts and incorrect readings of the Tyre Pressure Monitoring System (TPMS). Therefore, use the tyre repair kit pressure gauge to check and adjust the damaged tyre's inflation pressure.
11. Unscrew the inflation hose connector from the tyre valve, renew the tyre valve cap and the inflation hose connector protective cap.
12. Make sure that the tyre repair kit is placed securely in the vehicle.
13. Drive to the nearest tyre repair centre or Dealer/Authorised Repairer, for a replacement tyre to be fitted. Make sure that you make the repair centre aware that the tyre repair kit has been used before the tyre is removed.
14. The tyre inflation hose, the receiver and the sealant bottle must be renewed once a new tyre has been fitted.



Only sealant bottles which are completely empty should be disposed of with normal household waste. Sealant bottles which contain some sealant, and the tyre inflation hose, should be disposed of by a tyre specialist or your Dealer/Authorised Repairer in compliance with local waste disposal regulations.