CHANGING THE CONNECTED PHONE

Up to 10 mobile phones can be paired with the vehicle in the same way. However, only one can be connected and ready for use as a phone, at any one time.

To connect a different paired phone to the vehicle, follow the steps below:

- 1. From the Home menu, select Phone.
- **2.** A menu will appear. Select **Change phone**.
- Identify and select your phone from the displayed list.
- Once your phone is connected to the system, a confirmation message will be displayed, before switching to the **Digit** dialling screen.

TELEPHONE SYSTEM ICONS



Connect: Use to send or accept a call and access the Last 10 calls list.



Disconnect: Use to end or reject a call.



No phone connected.



Phone signal strength indicator.



Phone battery level indicator.



Bluetooth: Indicates that a Bluetooth® wireless technology device is connected.



Tick: Indicates that a Bluetooth® wireless technology device is paired.



Voicemail: Press and hold to dial the stored voicemail number.




Scroll bar up arrow: Use to scroll up lists of detected phones, calls or phonebook entries.



Scroll bar down arrow: Use to scroll down lists of detected phones, calls or phonebook entries.

STEERING WHEEL CONTROLS



E150938

- 1. Press to scroll back through received calls, the Last 10 list and finally to exit the list.
- Increase the volume when in a call, scroll up a displayed list or a number listed for a stored contact.
- 3. Press to scroll to the Last 10 list and received calls.
- Decrease the volume when in a call or scroll down a displayed list or a number listed for a stored contact.
- 5. Press to answer an incoming call. Press to end a call. Press and release to dial a number/contact. Press and release to access the Last 10 dialled list. Press and hold to access the phonebook list view.

Note: When scrolling through a phonebook or the Last 10 list, each contact is also displayed in the Message centre.