



When Limousine mode is switched on, the rear passengers will have control of the total cabin's Media system, and any shared sources via the remote control.

6. **Lock:** Touch to lock or unlock the Rear media remote control.
7. **System:** Touch to switch the selected Rear media system on or off.
8. Forward/Skip for the selected screen.
9. Touch to play the right rear screen's audio through the vehicle's speaker system.
- Note:** Only available when the Rear media system is in **Limo mode**.
10. **Source:** Touch to select the Rear media source selection menu.
11. Play/Pause for the selected screen.
12. Touch to play the left rear screen's audio through the vehicle's speaker system.
- Note:** Only available when the Rear media system is in **Limo mode**.
13. Rewind/Skip for the selected screen.
14. Rear media source selection menu: Touch the required media button.
15. **Source:** Touch to return to the **Rear media** control screen.

## REAR MEDIA REMOTE CONTROL



E151273

1. Press and release to switch off the screen.