Contents

Quick start

REMOTE CONTROL 9
CENTRAL LOCKING 10
TAILGATE 10
BONNET 11
POWER OPERATED SEAT ADJUSTMENT 11
DRIVING POSITION MEMORY 12
MANUAL SEAT ADJUSTMENT 12
WINDOWS AND DOOR MIRRORS 13
DOOR MIRROR ADJUSTMENT 13
POWER FOLD MIRRORS 13
STEERING COLUMN ADJUSTMENT 14
OVERHEAD CONSOLE 15
SEAT BELTS AND CHILD RESTRAINTS 16
CHILD SEATS 16
PASSENGER AIRBAG DEACTIVATION 16
HEATING AND VENTILATION 17
HEATED WINDSCREEN AND REAR WINDOW 19
SEAT HEATERS 19
FACIA 20
INSTRUMENT PACK 22
WARNING INDICATORS (ATTENTION) 23
WARNING INDICATORS (INFORMATION) 24
WINDSCREEN WIPER AND WASHER 24
DIRECTION INDICATORS AND HEADLAMP HIGH BEAM 25
EXTERIOR LAMPS MASTER SWITCH 25
ELECTRIC PARKING BRAKE (EPB) 26
AUTOMATIC TRANSMISSION 26
COMMANDSHIFT ™ 27
TRANSFER GEARBOX 27
HILL DESCENT CONTROL (HDC) 28
AIR SUSPENSION 28
TERRAIN RESPONSE SYSTEM 29
CRUISE CONTROL 30
AUDIO SYSTEMS 30
CD OPERATION 32
TELEPHONE - BLUETOOTH SYSTEM 33

Filling station information

FUEL FILLER FLAP 35
REFUELLING 35
TYRE PRESSURES 36
ENGINE OIL SPECIFICATION 36
ENGINE COOLANT SPECIFICATION 36

Introduction

SYMBOLS GLOSSARY 37
LABEL LOCATIONS 37
HEALTH AND SAFETY 38
DATA RECORDING 39
DISABILITY MODIFICATIONS 40
PARTS AND ACCESSORIES 40

Keys and remote controls

PRINCIPLE OF OPERATION 42
PROGRAMMING THE REMOTE CONTROL 42
GENERAL INFORMATION ON RADIO FREQUENCIES 44
USING THE KEY 44

Locks

LOCKING AND UNLOCKING 45

Engine immobiliser

PRINCIPLE OF OPERATION 48
CODED KEYS 48

Alarm

PRINCIPLE OF OPERATION 49
ARMING THE ALARM 49
SWITCHING OFF THE ALARM 51
TILT SENSOR 51
PANIC ALARM 51

Seats

SITTING IN THE CORRECT POSITION 52
MANUAL SEATS 53
ELECTRIC SEATS 54
HEAD RESTRAINTS 56
REAR SEATS 57
HEATED SEATS 62

Seat belts

GENERAL INFORMATION 63
SEAT BELT REMINDER 65
FASTENING THE SEAT BELTS 65
SEAT BELT HEIGHT ADJUSTMENT 66
USING SEAT BELTS DURING PREGNANCY 67

Contents

Supplementary restraints system

PRINCIPLE OF OPERATION 68
SIDE AIRBAGS 71
CURTAIN AIRBAGS 71
DISABLING THE PASSENGER AIRBAG 71
AIRBAG WARNING LAMP 73
AIRBAG SERVICE INFORMATION 74

Child safety

CHILD SEATS 75
CHILD SEAT POSITIONING 77
ISOFIX ANCHOR POINTS 79
BOOSTER CUSHIONS 81
CHILD SAFETY LOCKS 81

Steering wheel

ADJUSTING THE STEERING WHEEL 82
HORN 83
AUDIO CONTROL 83
VOICE CONTROL 84
CRUISE CONTROL 84

Lighting

GENERAL INFORMATION 85
LIGHTING CONTROL 86
FRONT FOG LAMPS 87
REAR FOG LAMPS 87
ADJUSTING THE HEADLAMPS 88
HEADLAMP LEVELLING 88
HAZARD WARNING FLASHERS 89
ADAPTIVE FRONT LIGHTING SYSTEM (AFS) 89
DIRECTION INDICATORS 91
INTERIOR LAMPS 92
REMOVING A HEADLAMP 93
REMOVING A REAR LAMP 94
CHANGING A BULB 95
BULB SPECIFICATION CHART 102

Wipers and washers

WINDSCREEN WIPERS 103
RAIN SENSOR 104
WINDSCREEN WASHERS 104
REAR WINDOW WIPER AND WASHERS 105
ADJUSTING THE WINDSCREEN WASHER JETS 106
HEADLAMP WASHERS 106
CHECKING THE WIPER BLADES 106
CHANGING THE WIPER BLADES 106

Windows and mirrors

ELECTRIC WINDOWS 108
EXTERIOR MIRRORS 109
ELECTRIC EXTERIOR MIRRORS 110
INTERIOR MIRROR 112

Instruments

INSTRUMENT PANEL OVERVIEW 113
GAUGES 114

Information displays

TRIP COMPUTER 115
PERSONALISED SETTINGS 116
INFORMATION MESSAGES 117

Climate control

AIR VENTS 119
MANUAL CLIMATE CONTROL 121
AUTOMATIC CLIMATE CONTROL 123
REAR PASSENGER CLIMATE CONTROLS 126
HEATED WINDOWS AND MIRRORS 126
AUXILIARY HEATER 127
ELECTRIC SUNROOF 127

Contents

Convenience features
SUN VISORS ... 129
SUN BLINDS ... 129
INSTRUMENT LIGHTING DIMMER ... 129
CLOCK ... 130
CIGAR LIGHTER ... 132
ASHTRAY ... 132
AUXILIARY POWER SOCKETS ... 133
CUP HOLDERS ... 134
CENTRE CONSOLE ... 135
COOL BOX ... 136
STORAGE COMPARTMENTS ... 137
MEMORY FUNCTION ... 138

Starting the engine
GENERAL INFORMATION ... 139
STARTER SWITCH ... 139
STEERING WHEEL LOCK ... 139
STARTING THE ENGINE ... 140
DIESEL PARTICULATE FILTER (DPF) ... 141

Transmission
MANUAL TRANSMISSION ... 142
AUTOMATIC TRANSMISSION ... 142
TRANSFER GEARBOX ... 146

Brakes
PRINCIPLE OF OPERATION ... 150
HINTS ON DRIVING WITH ABS ... 152
ELECTRIC PARKING BRAKE (EPB) ... 153

Parking aid
PRINCIPLE OF OPERATION ... 158
USING THE PARKING AID ... 158

Driving hints
RUNNING-IN ... 160
GENERAL DRIVING POINTS ... 160
REDUCED ENGINE PERFORMANCE ... 162
ECONOMICAL DRIVING ... 162

Cruise control
PRINCIPLE OF OPERATION ... 163
USING CRUISE CONTROL ... 163

Stability control
PRINCIPLE OF OPERATION ... 165
USING STABILITY CONTROL ... 165

Traction control
PRINCIPLE OF OPERATION ... 166

Hill descent control (HDC)
PRINCIPLE OF OPERATION ... 167
USING HDC ... 167

Terrain Response
PRINCIPLE OF OPERATION ... 170
USING TERRAIN RESPONSE ... 170

Air suspension
PRINCIPLE OF OPERATION ... 176
ADJUSTING THE SUSPENSION ... 177
AIR SUSPENSION MESSAGES ... 181

Fuel and refuelling
SAFETY PRECAUTIONS ... 183
FUEL QUALITY ... 183
ALTERNATIVE FUELS FOR PETROL ENGINES ... 184
DIESEL ENGINED VEHICLES ... 185
RUNNING OUT OF FUEL ... 186
FUEL FILLER FLAP ... 186
REFUELLING ... 187
FUEL CUT-OFF ... 188
CATALYTIC CONVERTER ... 188
FUEL CONSUMPTION ... 189

Load carrying
GENERAL INFORMATION ... 190
LUGGAGE ANCHOR POINTS ... 190
REAR LOADSPACE HATCHES ... 190
LUGGAGE COVERS ... 190

Towing
TOWING A TRAILER ... 193
LEVELLING ... 198
ESSENTIAL TOWING CHECKS ... 198
RECOMMENDED TOWING WEIGHTS ... 199
DETACHABLE TOW BALL ... 200
TOW BALL STOWAGE ... 202

Contents

Vehicle care
CLEANING THE EXTERIOR 203
CLEANING THE ALLOY WHEELS 205
CLEANING THE INTERIOR 205
REPAIRING MINOR PAINT DAMAGE 206

Maintenance
GENERAL INFORMATION 207
OPENING AND CLOSING THE BONNET 209
ENGINE COMPARTMENT OVERVIEW 210
UNDER BONNET COVERS 212
ENGINE OIL CHECK 212
ENGINE COOLANT CHECK 213
BRAKE FLUID CHECK 215
POWER STEERING FLUID CHECK 216
WASHER FLUID CHECK 217
TECHNICAL SPECIFICATIONS 218

Vehicle battery
BATTERY WARNING SYMBOLS 220
BATTERY CARE 220
USING BOOSTER CABLES 221
CHARGING THE VEHICLE BATTERY 223
CHANGING THE VEHICLE BATTERY 224
REFITTING THE VEHICLE BATTERY 225

Wheels and tyres
GENERAL INFORMATION 226
TOOL KIT 227
CHANGING A ROAD WHEEL 228
TYRE CARE 241
USING WINTER TYRES 246
USING SNOW CHAINS 246
TYRE PRESSURE MONITORING SYSTEM 247
TYRE GLOSSARY 251
TECHNICAL SPECIFICATIONS 252

Fuses
FUSE BOX LOCATIONS 253
CHANGING A FUSE 255
FUSE SPECIFICATION CHART 256

Status after a collision
DRIVING AFTER A COLLISION 262
INSPECTING SAFETY SYSTEM COMPONENTS 263

Vehicle recovery
TOWING POINTS 264
LASHING POINTS 266
TRANSPORTING THE VEHICLE 266
TOWING THE VEHICLE ON FOUR WHEELS 267

Vehicle identification
VEHICLE IDENTIFICATION NUMBER (VIN) 268
VEHICLE IDENTIFICATION PLATE 268
VEHICLE BUILD DATE PLATE 268

Technical specifications
TECHNICAL SPECIFICATIONS 269

Type approvals
TYPE APPROVALS 275

Audio introduction
RADIO RECEPTION 285

Audio unit overview
AUDIO UNIT OVERVIEW 286

Audio unit operation
ON/OFF CONTROL 288
VOLUME CONTROL 288
BASS/TREBLE CONTROL 291
BALANCE/FADE CONTROL 294
STATION PRESET BUTTONS 294
WAVEBAND BUTTON 295
AUTOSTORE CONTROL 295
TRAFFIC INFORMATION CONTROL 296

Audio unit menus
RADIO DATA SYSTEM (RDS) 297
NEWS BROADCASTS 297
PRIORITY PROGRAMME TYPE (PTY) 298

Audio unit clock and date displays
SETTING THE CLOCK AND DATE ON THE AUDIO UNIT 300

Contents

Compact disc player

LOADING COMPACT DISCS 301
EJECTING COMPACT DISCS 303
EJECTING MULTIPLE COMPACT DISCS 303
COMPACT DISC SELECTION 304
COMPACT DISC PLAYBACK 305
TRACK SELECTION 306
COMPACT DISC PAUSE 306
FAST FORWARD/REVERSE 306
COMPACT DISC FUNCTION MENU 307
SHUFFLE/RANDOM 307
REPEAT COMPACT DISC TRACKS 308
COMPACT DISC TRACK SCANNING 308
MP3 FILE PLAYBACK 309

Rear passenger controls

REAR SEAT CONTROLS 310
HEADPHONES 311

Auxiliary input (AUX IN) socket

AUXILIARY INPUT (AUX IN) SOCKET 312

Telephone

GENERAL INFORMATION 314
TELEPHONE CONTROLS 316
BLUETOOTH SETUP 318
TELEPHONE SETUP 319
USING THE TELEPHONE 320
PHONEBOOK 324
TELEPHONE VOICE CONTROL 327

Voice control

PRINCIPLE OF OPERATION 336
USING VOICE CONTROL 336
AUDIO UNIT COMMANDS 340
NOTEPAD COMMANDS 345

Television

GENERAL INFORMATION 346
TELEVISION CONTROLS 346
USING THE TELEVISION 347
TELEVISION SETUP 351