Engine immobiliser

PRINCIPLE OF OPERATION

Your vehicle is fitted with an engine immobiliser. The engine is immobilised automatically five seconds after the key is removed from the starter switch.

Note: *The engine will be re-mobilised automatically whenever the key is inserted into the starter switch. When this happens, the anti-theft alarm indicator illuminates briefly.*

CODED KEYS

Note: *A replacement remote control can only be obtained from your Land Rover Dealer/Authorised Repairer. The Dealer will require proof of ownership.*

Notify your Dealer immediately if a remote control is lost or stolen.