### General notes

- For the automatic temperature control system to function efficiently, all windows and the sunroof should be closed, and the air intake vents free from ice, snow, leaves or other debris.
- In very humid conditions, slight screen misting may be experienced when the air conditioning system is turned on. This is a natural occurrence and will clear after a few seconds.
- The air conditioning compressor will not work when the engine is off.
- Surplus water produced by the dehumidifying process is expelled beneath the vehicle. This may result in a small pool of water forming when the vehicle is stationary.

## HEATED SCREENS AND MIRRORS




Heated windscreen




Heated rear screen

Press button to operate the required screen heater. The screen heater(s) will operate for a timed period before automatically switching off.

The screen heaters will be automatically switched on if defrost mode is activated or if the external air temperature is low.

***Note:*** *The screen heaters only operate when the engine is running.*

**CAUTION**

To avoid damage to the heating elements, do not attach labels to the rear screen. Also, do not scrape or use abrasive materials to clean the inside of the rear screen.

### Exterior mirrors

The exterior mirrors automatically disperse ice or mist. The mirror heaters are controlled according to the external temperature and wiper status.