NOTE: Should the vehicle have a high proportion of short journeys or operate in severe conditions, Land Rover recommends that the maintenance intervals be cut in half. Contact your Land Rover retailer for additional information and recommendations.

	Maintenance Interval – whichever occurs first (based on expected vehicle display).									
Type	A	B	A	B	A	B	A	B	A	B
Miles x 1000	15	30	45	60	75	90	105	120	135	150
Months	12	24	36	48	60	72	84	96	108	120
SERVICE Kilometers x 1000	24	48	72	96	120	144	168	192	216	240
Change engine oil and replace filter	●	●	●	●	●	●	●	●	●	●
VEHICLE INTERIOR										
Reset the Service Interval Indicator	●	●	●	●	●	●	●	●	●	●
Reset engine oil level indicator	●	●	●	●	●	●	●	●	●	●
Check operation of all lights, warning indicators and horn	●	●	●	●	●	●	●	●	●	●
Check operation of front/rear wiper washer systems	●	●	●	●	●	●	●	●	●	●
Check condition and security of seats and seat belts		●		●		●		●		●
Replace pollen filter	●	●	●	●	●	●	●	●	●	●
VEHICLE EXTERIOR										
Check condition of wiper blades	●	●	●	●	●	●	●	●	●	●
Check operation of all door/flap/hood checks and catches; lubricate door checks	●	●	●	●	●	●	●	●	●	●
ENGINE COMPARTMENT										
Check battery condition; check / top up electrolyte level	●	●	●	●	●	●	●	●	●	●
Check / top up fluid levels (brake, power steering, windshield washer)	●	●	●	●	●	●	●	●	●	●
Check / top up coolant level; check specific gravity	●	●	●	●	●	●	●	●	●	●
Check condition of accessory drive belt(s) and, if fitted, supercharger drive belt	●	●	●	●	●	●	●	●	●	●
Change brake fluid: **every 3 years**			●			●			●	
Change engine coolant: **every 10 years**										●
Clean debris from auxiliary oil cooler (supercharged vehicles)	●	●	●	●	●	●	●	●	●	●
Replace spark plugs							●			
Replace fuel filter										●

	Maintenance Interval – whichever occurs first (based on expected vehicle display).									
Type	A	B	A	B	A	B	A	B	A	B
Miles x 1000	15	30	45	60	75	90	105	120	135	150
Months	12	24	36	48	60	72	84	96	108	120
SERVICE Kilometers x 1000	24	48	72	96	120	144	168	192	216	240
ENGINE COMPARTMENT (CONTINUED)										
Replace air cleaner elements					●					●
Replace accessory drive belt(s)										●
Replace supercharger drive belt (supercharged vehicles): **every 7 years**							●			
VEHICLE UNDERBODY										
NOTE: Remove all road wheels before inspecting brake components.										
Inspect brake pads for wear, calipers for leaks, and discs for condition	●	●	●	●	●	●	●	●	●	●
Lubricate wheel centers	●	●	●	●	●	●	●	●	●	●
Check adjustment of electronic parking brake	●	●	●	●	●	●	●	●	●	●
Inspect tire pressures, condition, and tread depth	●	●	●	●	●	●	●	●	●	●
Inspect exhaust system for leaks, security and damage	●	●	●	●	●	●	●	●	●	●
Inspect for fluid leaks	●	●	●	●	●	●	●	●	●	●
Inspect condition and operation of suspension and steering components		●		●		●		●		●
Inspect fuel, hydraulic and fluid pipes, hoses and unions		●		●		●		●		●
Inspect electrical harnesses, routing and connections		●		●		●		●		●
Replace all flexible brake hoses: **every 6 years**						●				
Change transmission fluid and filter: **every 10 years**										●
Change rear locking differential oil					●					●
Change front and rear axle oil (non-locking differential): **every 10 years**										●
Change transfer box oil; replace drain and fill plugs and washers					●					●
Remove debris from between Dynamic Response valve block and chassis	●	●	●	●	●	●	●	●	●	●
Replace filter in Dynamic Response valve block; replace lost fluid					●					●
Conduct road test; select LOW range gears and drive the vehicle 3 – 4 vehicle lengths, then reselect HIGH range gears	●	●	●	●	●	●	●	●	●	●