
RADIO CONTROLS



See **108, TOUCH SCREEN HOME MENU**.

1. **Radio**: Waveband selection. Touch to view and select a waveband. The radio will tune to the last used station on that waveband. Touch again to close.

   The waveband selection box will close automatically after 5 seconds without use.

2. Displays information about the current station. Some of this information is also displayed in the instrument panel.

3. Seek down:
   - Short touch to auto seek down the frequency to the next radio station.
   - Long touch to activate manual seek mode. Further short touches change the frequency in single decrements. A further long touch will scan backwards through the current waveband until the soft key is released.

4. Information. More information from the broadcasting station.

5. Seek up:
   - Short touch to auto seek up the frequency to the next radio station.
   - Long touch to activate manual seek mode. Further short touches change the frequency in single increments. A further long touch will scan forwards through the current waveband until the soft key is released.

6. **Settings**: Touch to view and activate/ deactivate the following features: **RDS**, **Traffic**, **News**, **AF** and **REG**. See **119, RADIO DATA SYSTEM (RDS)**.

7. **Station list** (FM only): Select to view a list of available stations on the waveband. The list can be sorted by **Frequency**, **Name** or **PTY** (pop, news, sport etc.), by selecting the appropriate soft key. Touch to select the chosen station.

   If the stations are sorted by category, touch the chosen category to view and select a corresponding station.