12. **NAVIGATION**. Press for direct access to the **Navigation** menu.

13. **PHONE**. Press for direct access to the **Telephone** menu.

14. Touch to select the **Off road Navigation** menu. Current set destination is displayed.

15. Touch to select **Phone**.

16. **Extra features**. Touch to display list.

17. Shortcut keys. Use for personal shortcuts to any part of the system. Shortcuts can be made in the **Set-up** menu.

TOUCH SCREEN USE

⚠ Always run the engine during prolonged use of the touch screen. Failure to do so may discharge the vehicle battery, preventing the engine from starting.

⚠ Avoid spilling or splashing liquids onto the touch screen.

Switching on

• Switch on the ignition.

• Switch on the touch screen.

   The most recently used audio source controls will be displayed (e.g. Radio, CD etc.).

• Select **HOME MENU**.

• Select a source.

Note: Available sources will depend upon options selected at time of purchase.

TOUCH SCREEN DISPLAY ICONS

Some touch screen display icons are displayed on subsequent screens and may not all be displayed at the same time, e.g.

 Back soft key: Touch to return to the previous screen displayed.

POP-UPS

Some menus and control screens will appear as pop-ups, overlaying the current screen.

Warning and information pop-ups may also appear on the display. Take notice of any warnings and follow any on-screen instruction.

HOME MENU

Press the hard key (**3**) at any time to move from the current display to the Home menu.

TOUCH SCREEN SET-UP

Select **Set-up** from the **Home menu**.

Set-up is divided into categories:

• Screen

• System

• Voice

SCREEN SETTINGS

• **Screensaver**: Select to change the screensaver. Touch an option to select.

• **Screen animations**: Select to turn animated transitions between screens on or off.

   Note: While screen animations are on, system response time will be slower than normal.

• **Time out home**: Sub menu selection screens can be set to revert to the **Home menu** after a pre determined length of time.

• **Theme**: Changes appearance of the touch screen soft keys.