Note: *Due to the duration of a* ***Bluetooth®*** *wireless technology search, it is advised that the time out to home screen feature is switched off before attempting to search for* ***Bluetooth®*** *wire less technology devices. This setting can be changed within* ***Set-up****,* ***Screen****,* ***Time out home****.*

CHANGING/DISCONNECTING A DEVICE

1. From the **Bluetooth** menu, select **Change device**.
2. Select **Disconnect**. A confirmation pop-up will appear and then you will be given the option to **Search new** or select a different device from the list of paired devices.