locking wheel nuts....246
recommended process....247
safety warnings....245
spare wheel....246
temporary spare wheel....246
tilt sensor....247
tool kit....245
use of spare tyre....246
Wheel chocks use....246
Wheels and tyres
age degradation....237
changing a tyre....240
checking the pressures after a repair....243
flat spots....236
full size replacements....240
Indian regulations....238
pressures....233
puncture repair....241
puncture repair safety....241
repair kit....241
repair kit use....241
repair procedure....242
replacements....236
snow chains....238
specifications....262
temporary use spare....240
TPMS....239
TPMS warning lamp....45
tyre care....233
tyre label....253
tyre speed ratings....233
tyre wall markings....232
valves....236
wheel alignment....258
winter tyres....237
Windows
anti-trap protection....66
operation....65
reset....207
Winter park position....206
Winter tyres....237
Wipers and washers....52
drip wipe....54
fluid level....216
rain sensor....53
speed-dependent mode....54
winter park position....54

X

Xenon headlamps....201