
TELEPHONE SYSTEM OVERVIEW



1. **Change phone**: Search for a new or change to another paired phone.
2. **Last 10**: Access the last 10 dialled, received, and missed calls.
3. **Phonebook**: Access the downloaded phonebook.
4. **Digit dial**: Access Digit dial mode.
5. Touch and hold to retrieve your voicemail.
6. Status display: Displays the name and/or number dialled and call duration.
7. Call Connect/Disconnect icons: Touch to send/accept or end/reject a call.
8. **Settings**: Access voicemail setup, Answer options, and Phone options.
9. Mute microphone: Initiate Privacy mode. While selected, the caller will not hear you talking.
10. Auto reject: When active, any incoming calls will be rejected or diverted to voicemail (depending on the mobile phone settings).
11. **Use handset**: Switch the call to your mobile phone.
12. **Delete**: Touch to delete the last entered digit, and hold to delete the whole entered number.

BLUETOOTH® INFORMATION

Bluetooth® is the name for short-range Radio Frequency (RF) technology that allows electronic devices to communicate wirelessly with each other.

The Land Rover **Bluetooth**® wireless technology system supports **Bluetooth**® Hands-Free Profile (HFP), Advanced Audio Distribution Profile (A2DP) and Audio Video Remote Control Profile (AVRCP).

Note: *HFP and A2DP/AVRCP profiles can be connected independently, so a phone can be connected via 1, while a media device can be connected via the other, at the same time.*