Note: *The Closing vehicle detection system is disabled when a trailer is attached.*

Note: *When BSM is disabled through the Instrument panel menu, the Closing vehicle detection system is also disabled. See* ***40, INSTRUMENT PANEL MENU****.*

BSM SENSORS

The BSM system will automatically disable if either of the sensors become completely obscured; an **amber** warning indicator dot (**2**) is displayed in the exterior mirror and the message **BLIND SPOT MONITOR SENSOR BLOCKED** appears in the Message centre.

Note: *Blockage testing is only initiated when the vehicle's speed is above 10 km/h (6 mph) and will take at least 2 minutes of accumulated driving above this speed, to determine that the sensor is blocked.*

If the sensors become blocked, then please check that there is nothing obscuring the rear bumper and that it is clear from ice, frost, and dirt.

If a fault with one of the radar sensors is detected, an **amber** warning indicator dot is displayed in the exterior mirror and the message **BLIND SPOT MONITOR NOT AVAILABLE** is displayed in the Message centre.

Note: *Even if the detected fault only affects the radar sensor on one side of the vehicle, the whole system is disabled. If the fault is temporary, the system will operate correctly once the engine has been switched off and then on again.*

If a fault in the system occurs, consult your Dealer/Authorised Repairer.