SEAT BELTS

Do not allow any water, cleaning products, or fabric from cloths to enter the seat belt mechanism. Any substance which enters the mechanism may affect the performance of the seat belt in an impact.

Extend the seat belts fully, then use warm water and a non-detergent soap to clean. Allow the seat belts to dry naturally while fully extended.

Note: *While cleaning the seat belt, take the opportunity to examine the webbing for damage/wear. Any wear or damage should be reported to, and rectified by, a Dealer/Approved Repairer.*

AIRBAG MODULE COVERS

Airbag covers should only be cleaned using a slightly dampened cloth, and a small amount of upholstery cleaner.

Do not allow the airbag covers, or surrounding areas, to become contaminated with liquids. Any substance which enters the mechanism can prevent correct deployment of an airbag during an impact.

INSTRUMENT PANEL, TOUCH SCREEN AND AUDIO SYSTEM

- Clean with a lightly moistened cloth.
- Do not use chemical agents or domestic cleaners.
- To prevent errors occurring, make sure that only one finger at a time is in contact with the Touch screen.
- Do not use excessive pressure.
- Do not allow sharp, hard, or abrasive objects to make contact with the Touch screen.
- Avoid exposing the Touch screen to direct sunlight for long periods.

BLOCKED WASHER JETS

Do not operate the washer jets during unblocking or adjustment. Windscreen washer fluid may cause irritation to the eyes and skin. Always read and observe the washer fluid manufacturer's instructions.

If a washer jet becomes blocked, use a thin strand of wire to unblock the jet, by inserting the wire into the jet. Make sure that the wire is completely removed after unblocking. The washer jet position may also be adjusted by inserting the point of a needle into the jet and gently repositioning it.