exterior....204
interior....205
leather....205
park assist sensors....204
parking aids sensors....204
seat belts....206
sensors and cameras....204
under body....204
washer jets....206
Climate control
automatic recirculation....69
auto setting....69
driver controls....
front....68
fuel burning heater....70
rear....70
remote control batteries....72
timed climate....70
timed climate remote controls....72
using the remote control....71
Clock....39
Clock settings
standard audio....133
Closing the bonnet....194
Closing vehicle sensing....58
Cold weather driving
diesel particulate filter (DPF)....193
Compact disc....135
Condensation (headlamps)....49
Conformity declarations....183, 264
Connecting jump leads....214
Controls
driving position....
overview....
standard audio system....123
Coolant
checking the level....209
specification....209
top up....209
Courtesy delay....48
Covers
refitting....194
removal....194
Critical warning messages....43
Cruise control....111
ACC driving hints....114
ACC follow mode....112
ACC gap change....113
ACC radar detection beam issues....114
ACC set speed and follow mode override....113
adaptive cruise control....112
adaptive cruise control malfunction....115
follow mode....112
forward alert in ACC....115
resume ACC follow mode....114
resume ACC set speed....114
using ACC....112
warning lamp....46

D

DAB radio
displayed messages....128–129
ensembles....127, 144
ensemble seek....127
manual tuning....128
settings....143
standard audio....127
standard radio presets....127
DAB radio controls....142
DAB service list....128
Data recording....250
Daytime running lamps....47
Dealer locations....176
Declarations of conformity....264
navigation system....183
Deselecting valet mode....67
Destination entry....172
postcode....175
search area....172
Detachable drawbar....84
removing....84
Detachable tow ball....82
removing....83
Detection beam issues....114
Diesel
filler flap....187
fuel....185

glow plugs
warning lamp....44
misfuel device....187
specification....184
sulphur content....185
water in fuel....187
Diesel particulate filter (DPF)....192
cold weather driving....193
driving short distances....193
sulphur content....185
Dimensions....256
Direction indicators....47
warning lamp....45
Disability modifications
airbags....37
Disabling the passenger air bag....37
Door mirrors....54
blind spot monitor
closing vehicle sensing....58
sensors....59
Door transceiver
assistance....62
erase all programming....61
garage door opener....60
programming....60
programming a single button....61
programming the garage door opener....60
rolling code device programming....61
Double locking....9
full alarm....9
Drawbar
detachable....84
Drawbar stowage....81
Drive away locking....7
Driver controls....
Driver exit
deactivating intelligent stop/start....93
Driving
ACC automatic switch-off....113
ACC driving hints....114
ACC follow mode....112
ACC forward alert....115
ACC gap change....113
ACC malfunction....115
ACC radar detection beam issues....114
ACC set speed and follow mode
override....113
activating intelligent stop/start....92
adaptive cruise control....112
after a collision....250
arduous conditions....192
before starting....250
blind spot monitor
closing vehicle sensing....58
blind spot monitor messages....59
brake control with ABS....102
brakes important information....102
daily checks....192
deactivating intelligent stop/start....92
driver controls....
DSC active warning lamp....44
electronic brake force distribution....102
emergency brake assist....102
forward alert....115
forward alert warning lamp....46
low oil pressure....43
rain sensor....53
resume ACC follow mode....114
resume ACC set speed....114
running-in....191
sitting correctly....14
steep slope control with ABS....102
using ACC....112
using cruise control....111
weekly checks....192
Driving abroad
beam pattern....49
headlamps....49
Driving position memory....14
Driving short distances
diesel particulate filter (DPF)....193
Dynamic stability control (DSC)....98
DSC active warning lamp....44
DSC off warning lamp....44
switching off....98
switching on....98