portable media playing.....181
Change a connected phone.....200
Changing a bulb.....236
Changing a fuse.....251
Changing a wheel
locking wheel nuts.....277
recommended process.....277
safety warnings.....274
spare wheel.....275
temporary spare wheel.....276
tool kit.....275
Charging the vehicle battery.....249
Chassis number.....288
Child safety
booster seats.....38
check list.....34
child seats.....33
ISOFIX anchor points.....36
larger children on booster seats.....38
lock and window inhibitor.....33
positioning.....35
recommended child seats.....35
tether straps.....37
Cleaning
after off-road driving.....237
airbag covers.....239
exterior.....237
interior.....238
leather.....239
park assist sensors.....237
parking aids sensors.....237
seat belts.....239
sensors and cameras.....237
under body.....237
Climate control
automatic recirculation.....80
front.....79
fuel burning heater.....82
heated and cooled seats.....80
rear.....86
remote control batteries.....85
timed climate.....83
timed climate remote controls.....85
using the remote control.....84
Climate seats.....80
Clock.....44
Closing the bonnet.....234
Closing vehicle sensing.....67
Cold weather driving
diesel particulate filter (DPF).....233
Compact disc.....168
Condensation (headlamps).....57
Conformity declarations.....222, 301
Connecting jump leads.....247
Convenience mode.....7
Coolant
checking the level.....243
specification.....243
top up.....243
Courtesy delay.....56
Covers
refitting.....235
removal.....235
Critical warning messages.....50
Cruise control.....153
ACC driving hints.....157
ACC emergency braking.....159
ACC follow mode.....154
ACC gap change.....155
ACC radar detection beam issues.....157
ACC set speed and follow mode override.....155
adaptive cruise control.....154
adaptive cruise control malfunction.....158
follow mode.....154
forward alert in ACC.....158
resume ACC follow mode.....156
resume ACC set speed.....156
using ACC.....154
warning lamp.....54

D

DAB radio
ensembles.....177
settings.....176
DAB radio controls.....175
Data recording.....287
Daytime running lamps.....55

Dealer locations....215
Declarations of conformity....301
navigation system....222
Deselecting valet mode....77
Destination entry....212
postcode....214
search area....211
Detection beam issues....157
Diesel
filler flap....225
fuel....224
glow plugs
warning lamp....51
misfuel device....226
sulphur content....224
water in fuel....226
Diesel particulate filter (DPF)....232
cold weather driving....233
driving short distances....233
sulphur content....224
Dimensions....296
Direction indicators....55
warning lamp....53
Disability modifications
airbags....43
Disabling the passenger air bag....41
Door mirrors....63
blind spot monitor
closing vehicle sensing....67
sensors....68
Door transceiver
assistance....71
erase all programming....70
garage door opener....69
programming....69
programming a single button....71
programming the garage door opener....69
rolling code device programming....70
Double locking....12
full alarm....12
Downloading from the internet
inControl connection....203
Drive away locking....7
Driver exit
deactivating intelligent stop/start....122
Driving
ACC automatic switch-off....156
ACC driving hints....157
ACC emergency braking....159
ACC follow mode....154
ACC forward alert....158
ACC gap change....155
ACC malfunction....158
ACC queue assist....156
ACC radar detection beam issues....157
ACC set speed and follow mode
override....155
activating intelligent stop/start....121
adaptive cruise control....154
after a collision....287
arduous conditions....232
automatic speed limiter....151
before starting....287
blind spot monitor
closing vehicle sensing....67
blind spot monitor messages....68
brake control with ABS....134
brakes important information....134
daily checks....231
deactivating intelligent stop/start....122
DSC active warning lamp....52
electronic brake force distribution....134
emergency brake assist....134
forward alert....158
forward alert warning lamp....54
gear shift warning lamp....53
hill start assist....134
intelligent braking....135
lane departure warning lamp (green)....54
lane departure warning lamp (red)....51
low oil pressure....50
park assist limitations....147
park assist troubleshooting....148
rain sensor....61
resume ACC follow mode....156
resume ACC set speed....156
running-in....230