selecting park assist....146
sitting correctly....17
steep slope control with ABS....134
using ACC....154
using cruise control....153
weekly checks....231
Driving abroad
beam pattern....57
headlamps....57
Driving aids
lane departure warning....137
traffic sign recognition....138
Driving short distances
diesel particulate filter (DPF)....233
Dual view....188
controls....188
Dynamic response
fluid level....245
fluid specification....246
fluid top up....246
Dynamic stability control (DSC)....129
DSC active warning lamp....52
DSC off warning lamp....52
switching off....129
switching on....129

E

Easy route....213
Eco-data controls....124
Electric mode....115
Electric parking brake....135
Electric rear seats
reclining....21
Electric seats....16
head restraint removal....26
head restraints....25
passenger seat away....22
position memory....18
restricted front seat travel....17
Electric windows
operation....72
Electronic brake force distribution....134
Electronic data....287
Email
inControl connection....203
Emergency (navigation)....214
Emergency brake assist....134, 159
Emergency call
inControl link....202
Emergency key locking....15
Engine
antifreeze level....243
compartment opening....234
coolant level....243
diesel fuel....224
diesel particulate filter (DPF)....232
engine compartment
poisonous fluids....234
oil level....241
petrol fuels....223
running-in....230
specifications....289
starting
keyless start backup....119
switching off....118
Engine/transmission warning lamp....51
Engine compartment
fluid filler locations....241
Engine covers
refitting....235
removal....235
Engine oil
capacity....292
Engine starting....118
failure to start....120
Engine temperature warning lamp....50
Ensembles for DAB radio stations....177
Entering a destination....212
Entering the vehicle
entry and exit mode....27
global opening....6
keyless entry....6
passive entry....6
unlocking mode....6
unlocking the steering column....27
Ethanol....223
EU conformity (navigation system)....222