running out....224
safety precautions....223
tank capacity....226
water in fuel....226
Fuel burning heater....82
Fuel consumption....228
combined cycles....229
extra-urban cycle....229
urban cycle....228
Fuel filler flap....225
Fuel gauge....44
Fuel system....233
Fuel tank
capacity....292
Full screen view for video....187
Fuses
changing....251
engine compartment fuse box....252
locations....250
luggage compartment fuse box....257
passenger compartment fuse box....254

G

Garage door opener....69
assistance....71
entry gate....71
erase all programming....70
programming....69
programming a rolling code device....70
programming a single button....71
Gearbox
automatic....125
emergency park release....284
gear shift warning lamp....53
hill descent....127
limp home mode....128
range change indicators....127
range changing....127
stationary range changing....127
General program....161
Global closing....13
Global opening....6
Glow plugs
warning lamp....51
Gradient release control
ascent brake release....164
Grass/gravel/snow....161

H

Handbook symbols....2
Handbrake....135
Hands free parking....145
park assist limitations....147
park assist troubleshooting....148
selecting park assist....146
Headlamps....55
adaptive....56
beam pattern....57
bulb changing....236
condensation....57
courtesy delay....56
daytime running lamps....55
driving abroad....57
high beam assist....56
high beam assist warning lamp....53
high beam warning lamp....53
warning lamp (AFS)....52
washers....61
Headphones....189
Head restraints....25
electric seats....25–26
Head up display....48
Heated steering wheel....27
Heating and ventilation....79
air quality sensor....80
automatic recirculation....80
front....79
fuel burning heater....82
heated and cooled seats....80
rear....86
remote control batteries....85
timed climate....83
timed climate remote controls....85
using the remote control....84
High beam assist....56
Hill descent control....163
brake release control....164
brake temperature....164