vehicle set-up....46
recommended tyre pressures....259
reduced hybrid display....45
service indicator....48
trip computer....47
trip distance....48
tyre pressure check....259
warning lamps....50
warning messages....46
Intelligent emegency braking
ACC....146
Intelligent stop/start
activating....110
deactivating....111
warning lamp....53
Intelligent stop/start warning lamp....53–54
Interior cleaning....230
airbag covers....231
Interior lamps....58
ambient lighting....59
bulb changing....222
intensity....59
stealth mode....59
types....58
Interior locking....14
Interior protection
temporary disabling....13
Internet browsing
InControl connection....190
ISOFIX anchor points....36

J

Jump starting
connecting a starting aid....240
connecting jump leads....239

K

Keyless entry....7
Keyless locking....13

L

Label locations....278
Lamps....55
bulb changing....222
condensation....57
rear lamp removal....226
test....50
TPMS warning lamp....53
warning lamps....50
xenon headlamps....224
Land Rover Assistance
InControl link....189
Lane departure warning....125
Lane departure warning lamp (green)....54
Lane departure warning lamp (red)....51
Leather cleaning....231
Licensing
audio/video....156, 158
Lighting
ambient lighting....59
interior lamps intensity....59
interior lamps locations....58
stealth mode....59
Limp home mode....117
Load carrying
luggage divider....93
Load securing....92
Loadspace cover....91
Locked access height....121
Locking
door locks and release levers....14
double locking....12
drive away....7
emergency locking....15
global closing....13
in an emergency....15
keyless....13
mislock....15
single....12
with the emergency key....15
Locking wheel nuts....267
Low fuel warning lamp....52
Low oil pressure warning lamp....50
Low range gearbox
selecting high range on the move....116
Low range transmission warning lamp....54
Lubricants specifications....281