fuel filler flap....212
methanol....210
methyl tertiary butyl ether (MTBE)....211
misfuel device....213
octane rating....210
petrol....210
running out....211
safety precautions....210
tank capacity....212
water in fuel....212
Fuel burning heater....81
Fuel consumption....214
combined cycles....215
extra-urban cycle....215
urban cycle....215
Fuel filler flap....212
Fuel gauge....44
Fuel system....219
Fuel tank
capacity....283
Full screen view for video....174
Fuses
changing....243
engine compartment fuse box....244
locations....242
luggage compartment fuse box....249
passenger compartment fuse box....246

G

Garage door opener....69
assistance....71
entry gate....70
erase all programming....70
programming....69
programming a rolling code device....70
programming a single button....70
Gearbox
automatic....114
emergency park release....274
gear shift warning lamp....53
hill descent....116
limp home mode....117
range change indicators....116
range changing....116
stationary range changing....116
General program....148
Global closing....13
Global opening....7
Glow plugs
warning lamp....52
Gradient release control
ascent brake release....151
Grass/gravel/snow....148

H

Handbook symbols....2
Handbrake....124
Hands free parking....133
park assist limitations....135
park assist troubleshooting....136
selecting park assist....134
Headlamps....55
adaptive....56
beam pattern....57
bulb changing....222
condensation....57
courtesy delay....56
daytime running lamps....55
driving abroad....57
halogen bulbs....225
high beam assist....56
high beam assist warning lamp....53
high beam warning lamp....53
removal....223
warning lamp (AFS)....52
washers....61
xenon....224
Headphones....176
Head restraints....24
electric seats....24
Head up display....48
Heated steering wheel....26
Heating and ventilation....78
air quality sensor....79
automatic recirculation....79
front....78
fuel burning heater....81
heated and cooled seats....79