D

DAB radio
ensembles....164
settings....163
DAB radio controls....162
Data recording....277
Daytime running lamps....55
Dealer locations....202
Declarations of conformity....292
navigation system....209
Deselecting valet mode....76
Destination entry....199
postcode....201
search area....198
Detection beam issues....144
Diesel
filler flap....212
fuel....211
glow plugs
warning lamp....52
misfuel device....213
sulphur content....211
water in fuel....212
Diesel particulate filter (DPF)....218
cold weather driving....219
driving short distances....219
sulphur content....211
Dimensions....287
Direction indicators....55
warning lamp....53
Disability modifications
airbags....43
Disabling the passenger air bag....41
Door mirrors....63
blind spot monitor
closing vehicle sensing....67
sensors....68
Door transceiver
assistance....71
erase all programming....70
garage door opener....69
programming....69
programming a single button....70
programming the garage door opener....69
rolling code device programming....70
Double locking....12
full alarm....12
Downloading from the internet
InControl connection....190
Drive away locking....7
Driver exit
deactivating intelligent stop/start....111
Driving
ACC automatic switch-off....143
ACC driving hints....144
ACC emergency braking....146
ACC follow mode....141
ACC forward alert....145
ACC gap change....142
ACC malfunction....145
ACC queue assist....143
ACC radar detection beam issues....144
ACC set speed and follow mode
override....142
activating intelligent stop/start....110
active exhaust....108
adaptive cruise control....141
after a collision....277
arduous conditions....218
automatic speed limiter....139
before starting....277
blind spot monitor
closing vehicle sensing....67
blind spot monitor messages....68
brake control with ABS....123
brakes important information....123
daily checks....217
deactivating intelligent stop/start....111
DSC active warning lamp....52
electronic brake force distribution....123
emergency brake assist....123
forward alert....145
forward alert warning lamp....54
gear shift warning lamp....53
hill start assist....123
lane departure warning lamp (green)....54
lane departure warning lamp (red)....51