Note: *The Closing vehicle detection system is disabled when a trailer is attached.*

Note: *When the BSM system is disabled through the Instrument panel menu (see* ***46, INSTRUMENT PANEL MENU****), the Closing vehicle detection system is also disabled.*

BSM SENSORS

The BSM system automatically disables if either of the sensors become completely obscured. An amber warning indicator dot (**2**) is displayed in the exterior mirror and the message **BLIND SPOT MONITOR SENSOR BLOCKED** appears in the Message centre.

Note: *Blockage testing is only initiated when vehicle speed is above 10 km/h (6 mph) and takes at least 2 minutes of accumulated driving above this speed, to determine that the sensor is blocked.*

If the sensors become blocked, please check that there is nothing obscuring the rear bumper and that it is clear from ice, frost and dirt.

If a fault with one of the radar sensors is detected, an amber warning indicator dot is displayed in the exterior mirror and the message **BLIND SPOT MONITOR NOT AVAILABLE** is displayed in the Message centre.

Note: *Even if the detected fault only affects the radar sensor on one side of the vehicle, the whole system is disabled. If the fault is temporary, the system operates correctly once the engine has been switched off and then on again.*

If a fault in the system occurs, consult your Dealer/Authorised Repairer.