
RADIO CONTROLS



Press the **AUDIO/VIDEO** button, or touch the **Audio/Video** icon from the Touch screen Home menu.

1. **AM/FM**: Waveband selection. Touch to view and select a waveband. The radio will tune to the last used station on that waveband. Touch again to close.
   The waveband selection box will close automatically after 5 seconds without use.
2. Displays information about the current station.
3. Seek down:
   - Short touch to auto seek down the frequency to the next radio station.
   - Long touch to activate manual seek mode. Further short touches change the frequency in single decrements. A further long touch will scan backwards through the current waveband until the soft key is released.

     Note: *When manual seek is selected, auto seek cannot be selected for approximately 10 seconds.*
4. Information: More information from the broadcasting station.
5. Seek up:
   - Short touch to auto seek up the frequency to the next radio station.
   - Long touch to activate manual seek mode. Further short touches change the frequency in single increments. A further long touch will scan forwards through the current waveband until the soft key is released.
6. **Settings**: Touch to view and activate/deactivate the following features: **RDS**, **Traffic**, **News**, **AF** and **REG**. See **161, RADIO DATA SYSTEM (RDS)**.
7. **Station list** (FM only): Select to view a list of available stations on the waveband. The list can be sorted by **Frequency**, **Name** or **PTY** (pop, news, sport etc.), by selecting the appropriate soft key. Touch to select the chosen station.