**NOTE: The maintenance intervals listed are for vehicles operating under normal driving, road, and climatic conditions. More frequent attention may be necessary if the vehicle is subject to routine stop & go driving, extreme temperatures, dusty conditions, off-road driving, or frequent trailer towing. Consult your Land Rover Retailer for more information.**

| | Maintenance Interval – whichever occurs first (based on expected vehicle display). | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| Miles x 1000 | 16 | 32 | 48 | 64 | 80 | 96 | 112 | 128 | 144 | 160 |
| Years | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| **SERVICE** Kilometers x 1000 | 26 | 52 | 78 | 104 | 130 | 156 | 182 | 208 | 234 | 260 |
| Change engine oil and replace filter | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| **VEHICLE INTERIOR** | | | | | | | | | | |
| Reset the Service Interval Indicator | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Reset engine oil level indicator | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Check operation of all lights, warning indicators and horn | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Check operation of front/rear wiper washer systems | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Check condition and security of seats and seat belts | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Replace pollen filter | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Replace climate controlled seat cushion motor filters (if equipped) | | ● | | ● | | ● | | ● | | ● |
| **VEHICLE EXTERIOR** | | | | | | | | | | |
| Check condition of wiper blades | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Check operation of all door checks, hood latch, and fuel flap; lubricate door checks | | ● | | ● | | ● | | ● | | ● |
| **ENGINE COMPARTMENT** | | | | | | | | | | |
| Check battery condition; check / top up electrolyte level | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Check / top up fluid levels (brake, coolant, Dynamic Response, windshield washer) | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Check specific gravity of coolant | | ● | | ● | | ● | | ● | | ● |
| Check condition of accessory drive belt(s) and, if fitted, supercharger drive belt | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Change brake fluid: **every 3 years** | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Change engine coolant: **every 10 years** | | | | | | | | | | ● |
| Clean debris from auxiliary oil cooler (supercharged vehicles) | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Replace spark plugs – 3.0L | **Every 96,000 miles** | | | | | | | | | |
| Replace spark plugs – 5.0L | **Every 112,000 miles** | | | | | | | | | |
| Replace air cleaner element | | | | ● | | | | ● | | |

Z3VlcXQ7MjAyNi0xMS0yMiQwNTo0OToyNC4yMDIwOzIxNi43My4yMTYuMjUyOw==



| | Maintenance Interval – whichever occurs first (based on expected vehicle display). | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| Miles x 1000 | 16 | 32 | 48 | 64 | 80 | 96 | 112 | 128 | 144 | 160 |
| Years | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| **SERVICE** Kilometers x 1000 | 26 | 52 | 78 | 104 | 130 | 156 | 182 | 208 | 234 | 260 |
| **ENGINE COMPARTMENT (CONTINUED)** | | | | | | | | | | |
| Replace accessory drive belt: **every 10 years** | | | | | | | | | | ● |
| Replace supercharger drive belt (supercharged vehicles): **every 7 years** | | | | | | | ● | | | |
| **VEHICLE UNDERBODY** | | | | | | | | | | |
| **NOTE:** Remove all road wheels before inspecting brake components. | | | | | | | | | | |
| Inspect brake pads for wear, calipers for leaks, and discs for condition | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Check operation of electronic parking brake | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Inspect tire pressures, condition, and tread depth | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Inspect exhaust system for leaks, security and damage | | ● | | ● | | ● | | ● | | ● |
| Inspect for fluid leaks | | ● | | ● | | ● | | ● | | ● |
| Inspect condition of driveshafts, suspension, and steering boots/gaiters | | ● | | ● | | ● | | ● | | ● |
| Inspect steering rod ball joint fixings and condition of ball joints, dust covers, and EPAS water drain valve | | ● | | ● | | ● | | ● | | ● |
| Inspect fuel, brake, hydraulic, Dynamic Response, and fluid pipes, hoses and unions | | ● | | ● | | ● | | ● | | ● |
| Inspect electrical harnesses, routing and connections | | ● | | ● | | ● | | ● | | ● |
| Check for free play in all suspension and body mounting bushings | | ● | | ● | | ● | | ● | | ● |
| Lubricate wheel spigot bore with anti-seize compound; install road wheels to opposite side of same axle (except unidirectional tires, which install on same side) | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Replace all flexible brake hoses: **every 6 years** | | | | | | ● | | | | |
| Change transmission fluid and filter | **Every 9 years** | | | | | | | | | |
| Change front and rear axle oil (non-locking differential) | **Every 10 years** | | | | | | | | | |
| Change transfer box oil; replace drain and fill plugs and washers | | | | | ● | | | | | ● |
| Replace Dynamic Response filter; replace lost fluid | | | | | ● | | | | | ● |
| Conduct road test; select LOW range gears and drive the vehicle 3 – 4 vehicle lengths, then reselect HIGH range gears | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| If fault lamps are illuminated, interrogate with IDS/SDD and report findings | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Check for any outstanding Recalls or Service Actions | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |