NOTE: The maintenance intervals listed are for vehicles operating under normal driving, road, and climatic conditions. More frequent attention may be necessary if the vehicle is subject to routine stop & go driving, extreme temperatures, dusty conditions, off-road driving, or frequent trailer towing. Consult your Land Rover Retailer for more information.

	Maintenance Interval – whichever occurs first (based on expected vehicle display).									
Miles x 1000	10	20	30	40	50	60	70	80	90	100
Years	1	2	3	4	5	6	7	8	9	10
SERVICE Kilometers x 1000	16	32	48	64	80	96	112	128	144	160
Change engine oil and replace filter	●	●	●	●	●	●	●	●	●	●
VEHICLE INTERIOR										
Reset the Service Interval Indicator	●	●	●	●	●	●	●	●	●	●
Check operation of all lights, warning indicators and horn	●	●	●	●	●	●	●	●	●	●
Check operation of front/rear wiper washer systems	●	●	●	●	●	●	●	●	●	●
Check condition and security of seats and seat belts		●		●		●		●		●
Replace pollen filter	●	●	●	●	●	●	●	●	●	●
VEHICLE EXTERIOR										
Check condition of wiper blades	●	●	●	●	●	●	●	●	●	●
Check operation of all door checks, hood latch, and fuel flap; lubricate hood catch		●		●		●		●		●
ENGINE COMPARTMENT										
Check battery condition; check / top up electrolyte level		●		●		●		●		●
Check / top up fluid levels (brake, coolant, windshield washer)	●	●	●	●	●	●	●	●	●	●
Check specific gravity of coolant		●		●		●		●		●
Check condition of accessory drive belt		●		●		●		●		●
Change brake fluid: **every 3 years**			●			●			●	
Change engine coolant: **every 10 years**										●
Replace spark plugs	**Every 110,000 miles**									
Replace air cleaner element		●		●		●		●		●
Replace accessory drive belt	**Every 9 years or 120,000 miles**									

Z3VtCkQ7MjAyNi0xMS0yMiQwNTo0OToyMy44NjZaOzIxNi43My4yMTYuMjUyOw==

	Maintenance Interval – whichever occurs first (based on expected vehicle display).									
Miles x 1000	10	20	30	40	50	60	70	80	90	100
Years	1	2	3	4	5	6	7	8	9	10
SERVICE Kilometers x 1000	16	32	48	64	80	96	112	128	144	160
VEHICLE UNDERBODY										
NOTE: Remove all road wheels before inspecting brake components.										
Inspect brake pads for wear, calipers for leaks, and discs for condition	●	●	●	●	●	●	●	●	●	●
Check operation of electronic parking brake	●	●	●	●	●	●	●	●	●	●
Inspect tire pressures, condition, and tread depth	●	●	●	●	●	●	●	●	●	●
Inspect exhaust system for leaks, security and damage	●	●	●	●	●	●	●	●	●	●
Inspect for fluid leaks	●	●	●	●	●	●	●	●	●	●
Inspect condition of driveshafts, suspension, and steering boots/gaiters	●	●	●	●	●	●	●	●	●	●
Check for free play in all suspension mounting bushings	●	●	●	●	●	●	●	●	●	●
Inspect fuel, brake, hydraulic and fluid pipes, hoses and unions	●	●	●	●	●	●	●	●	●	●
Inspect electrical harnesses, routing and connections	●	●	●	●	●	●	●	●	●	●
Lubricate wheel spigot bore with anti-seize compound	●	●	●	●	●	●	●	●	●	●
Install road wheels	●	●	●	●	●	●	●	●	●	●
Replace all flexible brake hoses: **every 6 years**						●				
Change transmission fluid	**Every 10 years**									
Conduct road test	●	●	●	●	●	●	●	●	●	●
If fault lamps are illuminated, interrogate with IDS/SDD and report findings	●	●	●	●	●	●	●	●	●	●
Check for any outstanding Recalls or Service Actions	●	●	●	●	●	●	●	●	●	●