NOTE: The maintenance intervals listed are for vehicles operating under normal driving, road, and climatic conditions. More frequent attention may be necessary if the vehicle is subject to routine stop & go driving, extreme temperatures, dusty conditions, off-road driving, or frequent trailer towing. Consult your Land Rover Retailer for more information.

	Maintenance Interval – whichever occurs first (based on expected vehicle display).									
Miles x 1000	16	32	48	64	80	96	112	128	144	160
Years	1	2	3	4	5	6	7	8	9	10
SERVICE Kilometers x 1000	26	52	78	104	130	156	182	208	234	260
Change engine oil and replace filter	●	●	●	●	●	●	●	●	●	●
VEHICLE INTERIOR										
Reset the Service Interval Indicator	●	●	●	●	●	●	●	●	●	●
Reset engine oil level indicator	●	●	●	●	●	●	●	●	●	●
Check operation of all lights, warning indicators and horn	●	●	●	●	●	●	●	●	●	●
Check operation of front/rear wiper washer systems	●	●	●	●	●	●	●	●	●	●
Check condition and security of seats and seat belts	●	●	●	●	●	●	●	●	●	●
Replace pollen filter	●	●	●	●	●	●	●	●	●	●
Replace climate controlled seat cushion motor filters (if equipped)		●		●		●		●		●
VEHICLE EXTERIOR										
Check condition of wiper blades	●	●	●	●	●	●	●	●	●	●
Check operation of all door checks, hood latch, and fuel flap; lubricate door checks		●		●		●		●		●
ENGINE COMPARTMENT										
Check battery condition; check / top up electrolyte level	●	●	●	●	●	●	●	●	●	●
Check / top up fluid levels (brake, coolant, windshield washer)	●	●	●	●	●	●	●	●	●	●
Check specific gravity of coolant		●		●		●		●		●
Check condition of accessory drive belt(s)	●	●	●	●	●	●	●	●	●	●
Change brake fluid: **every 3 years**	●	●	●	●	●	●	●	●	●	●
Change engine coolant: **every 10 years**										●
Replace spark plugs	**Every 96,000 miles**									
Replace air cleaner element				●				●		

Z3VtcXQ7MjAyNi0xMS0yMiQxMjowNDowMC45MzYxOzIxNi43My4yMTYxMFUyOw==

	Maintenance Interval – whichever occurs first (based on expected vehicle display).									
Miles x 1000	16	32	48	64	80	96	112	128	144	160
Years	1	2	3	4	5	6	7	8	9	10
SERVICE Kilometers x 1000	26	52	78	104	130	156	182	208	234	260
ENGINE COMPARTMENT (CONTINUED)										
Replace accessory drive belt: **every 10 years**										●
VEHICLE UNDERBODY										
NOTE: Remove all road wheels before inspecting brake components.										
Inspect brake pads for wear, calipers for leaks, and discs for condition	●	●	●	●	●	●	●	●	●	●
Check operation of electronic parking brake	●	●	●	●	●	●	●	●	●	●
Inspect tire pressures, condition, and tread depth	●	●	●	●	●	●	●	●	●	●
Inspect exhaust system for leaks, security and damage		●		●		●		●		●
Inspect for fluid leaks		●		●		●		●		●
Inspect condition of driveshafts, suspension, and steering boots/gaiters		●		●		●		●		●
Inspect steering rod ball joint fixings and condition of ball joints, dust covers, and EPAS water drain valve		●		●		●		●		●
Inspect fuel, brake, hydraulic, and fluid pipes, hoses and unions		●		●		●		●		●
Inspect electrical harnesses, routing and connections		●		●		●		●		●
Check for free play in all suspension and body mounting bushings		●		●		●		●		●
Lubricate wheel spigot bore with anti-seize compound; install road wheels to opposite side of same axle (except unidirectional tires, which install on same side)	●	●	●	●	●	●	●	●	●	●
Replace all flexible brake hoses: **every 6 years**						●				
Change transmission fluid and filter	**Every 9 years**									
Change front and rear axle oil (non-locking differential)	**Every 10 years**									
Change rear locking differential oil					●					●
Change transfer box oil; replace drain and fill plugs and washers					●					●
Conduct road test; select LOW range gears and drive the vehicle 3 – 4 vehicle lengths, then reselect HIGH range gears	●	●	●	●	●	●	●	●	●	●
If fault lamps are illuminated, interrogate with IDS/SDD and report findings	●	●	●	●	●	●	●	●	●	●
Check for any outstanding Recalls or Service Actions	●	●	●	●	●	●	●	●	●	●