PORTABLE MEDIA PAIRING AND CONNECTING USING THE TOUCH SCREEN

1. Switch on the device's **Bluetooth®** wireless technology device connection. Make sure that it is in **Bluetooth** wireless technology device discoverable mode, sometimes referred to as 'find me' mode (see the device's operating instructions for more information).
2. Switch on the ignition and make sure the Touch screen is active. See **84, TOUCH SCREEN HOME MENU**.
3. From the **Home menu**, select the Media menu and then select **My Music**. See **187, PORTABLE MEDIA CONTROLS**.
4. Touch the **Bluetooth** soft key.
5. A menu will appear. Select the **Change device** soft key.
6. Select the **Vehicle to device** soft key.
7. Identify the device from the displayed list and select the corresponding **Pair and connect** option.

   Note: *If more than 5 devices are detected, it may be necessary to use the scroll bar to see the entire list.*
8. When prompted, enter the Personal Identification Number (PIN) code into the device. See the device's operating instructions for more information.
9. Once the device is paired and connected to the system, a confirmation message will be displayed before switching to the **My music**, **Bluetooth** view.

Note: *Due to the duration of a* ***Bluetooth*** *wireless technology device search, it is advised that the time out to home screen feature is switched off before attempting to search for* ***Bluetooth*** *wireless technology devices. This setting can be changed by selecting* ***Screen*** *from the* ***Setup*** *menu, and then selecting* ***Time out to home menu****.*

CHANGING/DISCONNECTING A DEVICE

1. Switch on the ignition and make sure the Touch screen is active. See **84, TOUCH SCREEN HOME MENU**.
2. From the **Home menu**, select the Media menu, and then select **My Music**. See **187, PORTABLE MEDIA CONTROLS**
3. Touch the **Bluetooth** soft key.
4. From the **Bluetooth** menu, select **Change device**.
5. Select **Disconnect**. A confirmation pop-up will appear and then you will be given the option to **Search new** or select a different device from the list of paired devices.