Global closing.....18
Global opening.....7
Glow plugs
warning lamp.....61
Gradient release control
ascent brake release.....172
Grass/gravel/snow.....168

H

Handbook symbols.....2
Handbrake.....139
Hands free parking.....150
park assist limitations.....152
park assist troubleshooting.....153
selecting park assist.....151
Hands free tailgate opening.....12
Hazard warning lamps
emergency stop signal.....140
Headlamps.....64
adaptive.....66
beam pattern.....66
bulb changing.....258
condensation.....66
courtesy delay.....65
daytime running lamps.....65
driving abroad.....66
halogen bulbs.....260
high beam assist.....65
high beam assist warning lamp.....62
high beam warning lamp.....63
removal.....259
warning lamp (AFS).....60
washers.....71
xenon.....258
Headphones.....199
Head restraints.....29
electric seats.....29
Head up display.....56
Heated steering wheel.....32
Heating and ventilation.....88
air quality sensor.....90
automatic recirculation.....89
front.....88
fuel burning heater.....91
heated and cooled seats.....90
rear.....95
remote control batteries.....94
timed climate.....92
timed climate remote controls.....94
using the remote control.....93
High beam assist.....65
Hill descent control.....171
brake release control.....172
brake temperature.....172
warning lamp.....62
warning messages.....172
Hill start assist.....140
Hitch guidance cameras.....107
Home (navigation).....230
Homelink.....78
assistance.....79
erase all programming.....79
programming.....78
programming a single button.....79
programming the garage door opener.....78
Hybrid vehicle
electric mode.....116
hybrid system battery fault.....59
instrument panel.....51–52
power gauge.....51
reduced hybrid display.....52
storing.....252
system overview.....116
warning messages.....118

I

Ignition
rolling re-start.....121
switching on.....120
InControl
apps.....221
overview.....215
protect.....215
remote premium.....217
secure.....219
wi-fi connection.....219
Indicators warning lamp.....61