Vehicle battery
battery monitoring system.....283
connecting jump leads.....280
effects of disconnection.....282
removing.....282
replacing.....282
warning symbols.....279
Vehicle battery care.....279
Vehicle cleaning
after driving off-road.....267
airbag covers.....270
alloy wheels.....268
engine compartment.....266
interior.....268–269
under body.....266
washer jets.....270
Vehicle data recording.....325
Vehicle loading tyre pressures.....305
Vehicle location
InControl secure.....219
Vehicle recovery
front towing eye.....319
off-road.....322
rear towing eye.....319
steering column lock.....9
towing on four wheels.....322, 324
transmission park release.....321
transporting the vehicle.....322
unlocking the steering column.....322
Vehicle storage.....252
Vehicle testing on rolling roads.....254
Video media player
controls.....196
dual view.....198
controls.....198
headphones.....199
full screen view.....197
headphones.....203
inhibited display.....197
rear media touch screen control.....200
rear media use.....202
VIN number.....327
Voice control.....205
navigation POI categories.....207
recognising your voice.....206
settings
command list.....207
operating guide.....207
preferences.....207
voicetags.....207
voice training.....207
training the system.....206
tutorial.....206
voicetags.....207
Voice guidance.....229
Volume
telephone.....213

W

Wade sensing
controls.....173
Wading depth
touch screen aid.....173
Warning lamps.....58, 61–62
ABS.....60
ACC follow mode.....61
adaptive front lighting system (AFS).....60
airbags.....48, 60
automatic speed limiter.....60
battery charge.....58
brake.....58, 60
critical warning message.....59
cruise control.....61
diesel glow plugs.....61
DSC active.....60
engine/transmission.....60
engine temperature.....59
external temperature.....61
forward alert.....62
gear shift warning lamp.....62
HDC.....62
headlamp high beam.....63
high beam assist.....62
hybrid vehicle battery fault.....59
indicators.....61
intelligent stop/start (green).....62
intelligent stop/start (white).....63

lamp test....58
lane departure (green)....62
lane departure (red)....59
low fuel....61
low oil pressure....59
low range selected....62
parking brake....59
progress control system....61
rear fog lamps....61
seat belt....59
side lights....62
trailer direction indicators....62
tyre pressure monitoring system (TPMS)....61
Warning messages....54
hybrid vehicles....118
Washer jets....270
Washer reservoir capacity....332
Washers....69
fluid specification....277
fluid top up....277
headlamps....71
Water in fuel....245
Web browsing
InControl connection....219
Weights
gross vehicle weights....334
roof load....334
roof rack weight....334
tow ball/hitch....105
towing....105
vehicle weights....334
Wheel changing
important information....314
locking wheel nuts....315
recommended process....315
safety warnings....312
spare wheel....313
temporary spare wheel....315
tilt sensor....315
tool kit....313
use of spare tyre....314
Wheel chocks use....315
Wheels and tyres
age degradation....300
changing a tyre....306
checking the pressures after a repair....310
flat spots....299
full size replacements....305
Indian regulations....303
pressures....297
puncture repair....307
puncture repair safety....307
repair kit....307
repair kit use....308
repair procedure....308
replacements....299
snow chains....302
temporary use spare....306
TPMS....304
TPMS warning lamp....61
tyre care....296
tyre speed ratings....296
tyre wall markings....295
ultra high performance tyres....301
valves....298
winter tyres....300
Wheel spin....131
Wi-Fi
InControl connection....219
Windows
anti-trap protection....82
operation....81
reset....264
solar attenuating....83
sunroof reset....264
Winter park position....264
Winter tyres....300
Wipers....69
Wipers and washers....69
fluid level....277
rain sensor....70
speed-dependent mode....70
winter park position....71