E

Effects of battery disconnection....88
Electric windows
operation....25
Electrolyte level
battery condition....85
Emergency key access
entering the security code....5
Engine
antifreeze level....79
compartment opening....69
coolant level....79
diesel fuel....63
diesel particulate filter (DPF)....67
engine compartment
poisonous fluids....69
engine malfunction warning lamp....29
malfunction warning lamp....29
oil level....78
specifications....105
Engine compartment
fluid filler locations....78
Engine starting....43
Exiting the vehicle
arming the alarm....8
closing mislock....8
door locks and release levers....8
interior locks....8
Exterior cleaning....75
Exterior lamps
bulb changing....70
bulb specification....113
Exterior mirrors
electric....27
manual....27

F

Fluids
brake
check....81
specification....81
top up....81
capacities....111
clutch check....80
clutch fluid specification....80
clutch fluid top up....80
coolant
specification....79
top up....79
engine oil check....78
filler locations....78
oil
top up....79
power steering
specification....83
power steering check....82
specifications....112
washer fluid....82
check....82
specification....82
Fog lamps
warning lamps
rear....30
Front climate control....31
Front wipers....24
Fuel and refuelling....64
consumption....66
diesel....63
diesel fuel sulphur content....63
filler flap....64
fuel filler cap....64
fuel specification....66
running out....63
safety precautions....63
Fuel consumption....66
Fuel filler cap....64
Fuel gauge....28
Fuel system....69
Fuse box
passenger compartment....90
Fuses
changing....89
locations....89
passenger compartment fuse box....90
secondary fuse box....91