DISABILITY MODIFICATIONS

Occupants with disabilities which may require modification of the vehicle, must contact a Dealer/Authorised Repairer before any modifications are made.

OWNER MAINTENANCE

Any significant or sudden drop in fluid levels, or uneven tyre wear, should be reported to a qualified technician without delay.

Regular systematic maintenance is the key to making sure of the continued reliability and efficiency of your vehicle.

Maintenance is the owner's responsibility and you must make sure that owner maintenance operations, oil services, inspections and brake fluid and coolant changes are carried out when required and according to the manufacturer's recommendations.

The routine service requirements for your vehicle are shown in the Service Record and Warranty Benefits book. Most of this necessary workshop maintenance requires specialised knowledge and equipment and should be entrusted to a Land Rover Dealer/Authorised Repairer.

In addition to the routine maintenance, a number of simple checks must be carried out more frequently.

DAILY CHECKS

- Operation of lamps, horn, direction indicators, wipers, washers and warning indicators.
- Operation of seat belts and brakes.
- Look for fluid deposits underneath the vehicle that might indicate a leak.

WEEKLY CHECKS

- Engine oil level.
- Engine coolant check.
- Brake/clutch fluid level.
- Power steering fluid level.
- Screen washer fluid level.
- Tyre pressures and condition.
- Operate air conditioning.

Note: *The engine oil level should be checked more frequently if the vehicle is driven for prolonged periods at high speeds.*

SERVICE INTERVAL INDICATOR

OIL SERVICE appears in the instrument panel, when starting the vehicle or with the ignition turned on, to indicate when an oil service is due. When this message appears, the vehicle should be taken to a dealer/authorised repairer at the earliest opportunity.

Note: *Failure to service the vehicle when instructed to do so by the service interval indicator may invalidate the warranty.*

DIESEL PARTICULATE FILTER (DPF)

Diesel vehicles equipped with a particle filter have more efficient emission control. The particles in the exhaust gases are collected in the filter during normal driving.