## Controls overview

## CONTROLS

- 1. Map reading lamp switch.
- 2. Main interior lamp switch.
- 3. Sunroof open/close switch.
- 4. Air bag status indicator.
- **5.** Adaptive cruise control gap setting.
- High beam/Turn signals/Trip computer switch
- 7. Audio system control.
- 8. Instrument panel and message center.
- 9. Vehicle information control.
- 10. Wiper/washer controls.
- 11. START/STOP button.
- 12. Master locking switch.
- 13. Hazard warning lamp switch.
- 14. Display/touch screen.
- **15.** Audio system and controls.
- 16. Glove box switches.
- **17.** Heater/air conditioning control.
- 18. Tailgate opener.
- 19. Parking aid switch.
- 20. Transfer gear switch.
- **21.** Electric parking brake.
- 22. Hill descent control (HDC) switch.
- 23. Air suspension switch.
- 24. Terrain response control.
- 25. Main gearbox selector
- **26.** Rear climate control master switch.
- **27.** Dynamic stability control switch.
- 28. Telephone controls.
- **29.** Voice recognition switch.
- **30.** Heated steering wheel switch.
- 31. Horn switches.
- 32. Cruise control switches.

- 33. Electric steering column adjuster.
- 34. Hood release.
- 35. Instruments, clock and switches illumination dimmer control.
- **36.** Rear fog lamp switch.
- **37.** Front fog lamp switch.
- **38.** Lamps master switch.
- 39. Electric mirror controls.
- 40. Mirror selector switch.
- 41. Flectric window controls.
- 42. Electric window rear isolator switch
- 43. Power folding mirrors.
- **44.** Air suspension access height switch.

