

## Controls overview


## **CONTROLS**

- 1. Roof blind switch.
- 2. Front interior courtesy lamp.
- 3. Front map/reading lamps.
- 4. Exterior lights/trip computer control.
- 5. Audio system control.
- **6.** Instrument pack and message center.
- 7. Instrument pack menu control.
- 8. Wipers and washers control.
- 9. START/STOP button.
- 10. Touch screen display.
- 11. Audio system.
- 12. Hazard warning lights switch.
- 13. Heater/Air conditioning.
- 14. Hill Descent Control (HDC) switch.
- **15.** Dynamic Stability Control (DSC) switch.
- 16. Automatic transmission drive selector.
- **17.** Terrain response.
- 18. Electric parking brake.
- 19. Audio on/off/volume switch.
- 20. Upshift gear paddle.
- 21. Cruise control cancel switch.
- 22. Cruise control switches.
- 23. Steering column adjustment lever.
- 24. Horn.
- 25. Telephone and voice control switches.
- 26. Headlamp levelling control.
- 27. Interior illumination control.
- 28. Hood release lever.
- **29.** Tailgate release/open switch.
- **30.** Heated steering wheel switch.
- 31. Downshift gear paddle.
- 32. Rear window isolator switch.
- 33. Window switches.

- **34.** Mirror adjustment/power folding switches.
- **35.** Central locking/unlocking switches.
- **36.** Driving position memory switches.







SL1969