
TOUCH SCREEN HOME MENU

Note: Physical controls are referred to as hard keys. Virtual buttons on the touch screen are referred to as soft keys.

Screen options will vary depending on vehicle specification and set-up.



SL2119

- Screen on/off. The first use after switching the ignition on will display the Home Menu. Subsequent switching on will display the last used screen or menu.
- 2. SETTINGS. Press for direct access to the settings menu. When Park assist is specified, the icon is changed and the button will turn Park assist on and off. The Settings menu is then accessed via the touch screen.
- HOME MENU. Press for direct access to the Home menu. Content will depend upon vehicle specification and options selected.
- 4. Touch to select the Set-up menu.
- 5. Touch to select Valet mode.

- Touch to select the Audio/Video menu. An overview of current audio/video information is displayed.
- 7. Touch to select the **On road Navigation** menu. Current set destination is displayed.
- 8. While navigation is operating, touch to repeat the last given navigation instruction. During a phone call, the icon is temporarily changed. Touch to end the call.
- **9.** Time display. Touch to select time or date adjustment.
- **10. MODE**. Press repeatedly to scroll through all audio/video sources.
- **11. AUDIO VIDEO**. Press for direct access to the **Audio/Video** menu.
- **12. NAVIGATION**. Press for direct access to the **Navigation** menu.