- Rear bumper rotate the two fasteners 90 degrees counter clockwise. Pull the panel away from the rear bumper.
- **3.** If the Dynamic pack is fitted, the exhaust finisher will also require removal before the towing point can be used.

Installation of the panels is the reverse of removal.

NOTICE

Remove the front and rear towing point covers before driving off-road, to prevent damage or loss.

OFF-ROAD RECOVERY

If the towing points are to be used for off-road recovery, it is essential that off-road driver training covering recovery techniques is undertaken.

Further information on off-road driver training can be found at http://www.landroverexperience.com

TOWING THE VEHICLE ON FOUR WHEELS

The vehicle should **NOT** be towed on all four wheels. However, if the vehicle cannot be recovered by using the correct method, please adhere to the following guidelines.

AWARNING

If the engine cannot be used during towing, there will be no power assistance to the braking. This will result in much greater effort to stop the vehicle and in a greatly increased stopping distance.

NOTICE

If the vehicle battery is disconnected or disabled, do NOT attempt to tow the vehicle. Towing may result in serious damage to the transmission.

NOTICE

If the vehicle must be towed, only tow in a forward direction with all four wheels on the ground. Towing in a reverse direction or with only two wheels on the ground, will cause serious damage to the transmission.

NOTICE

Do not tow the vehicle if the transmission cannot be set in **N**.

NOTICE

The following is **NOT** recommended practice. With the front wheels suspended, the vehicle can be towed for a maximum of only 30miles (50km), at a maximum speed of 30mph (50km/h). Towing for a greater distance or at a higher speed, may result in serious damage to the transmission. It is advisable to have the transmission checked by your Land Rover Retailer/Authorized Repairer.

In an emergency, the vehicle can be towed on all four wheels for a very short distance but it is advisable to have the transmission checked by your Land Rover Retailer/Authorized Repairer.

If the engine is switched off with N selected, the transmission will wait for 10 minutes before selecting P. At this point if the vehicle is being towed, serious damage to the transmission will result.There is also a danger to personal safety.

The following procedure must be carried out:

1. Secure the towing attachment from the recovery vehicle to the front towing point.