

When the subscription process is complete the activation signal will be sent. The Sirius operative will advise on how long activation will take.

When your vehicle receives the signal, the SAT Radio display area will show a percentage download figure. When that reaches 100%, activation is complete.

Once you have started this process, do NOT switch the audio system off until activation is complete.

Note: *With a Bluetooth® phone paired and connected to the vehicle, you can touch the green phone icon to call the SIRIUS subscription line.*

SATELLITE RADIO RECEPTION

Satellite radio can significantly increase the number of radio channels available.

Where satellite signal strength is adversely affected by terrain, ground transmitters are used to relay the signal.

Note: *If any auxiliary electrical equipment is connected to the vehicle, then this may reduce the radio sound quality.*

SONG SEEK

If a subscribed channel is broadcasting a track that is stored in the song memory, a pop-up will be displayed giving you the option to tune to the channel playing that track.

SATELLITE RADIO CHANNEL UPDATE

Channel line-ups will be automatically updated. When this occurs, the audio will mute and **Updating channels...** is displayed along with a progress bar. Once the update is complete, the radio will tune to the last tuned channel or if the last tuned channel is now invalid, the radio will tune to the lowest channel number available.