

**A**

|                                                |     |
|------------------------------------------------|-----|
| ABS (Anti-lock braking system)                 |     |
| warning lamp . . . . .                         | 69  |
| ACC                                            |     |
| follow mode . . . . .                          | 69  |
| ACC (Adaptive cruise control) . . . . .        | 128 |
| automatic switch-off . . . . .                 | 130 |
| driving hints . . . . .                        | 131 |
| fault . . . . .                                | 132 |
| follow mode . . . . .                          | 129 |
| gap change . . . . .                           | 129 |
| malfunction . . . . .                          | 132 |
| operating . . . . .                            | 128 |
| override . . . . .                             | 130 |
| resume follow mode . . . . .                   | 130 |
| resume set speed . . . . .                     | 130 |
| Adaptive front lighting system (AFS)           |     |
| warning lamp . . . . .                         | 69  |
| AFS (Adaptive front lighting system) . . . . . | 50  |
| Air bags . . . . .                             | 43  |
| deployment effects . . . . .                   | 46  |
| disability modifications . . . . .             | 48  |
| front . . . . .                                | 43  |
| module covers . . . . .                        | 199 |
| occupant sensing . . . . .                     | 46  |
| operation . . . . .                            | 44  |
| service information . . . . .                  | 47  |
| side and curtain . . . . .                     | 44  |
| SRS (Supplementary restraint system) . . . . . | 191 |
| warning lamp . . . . .                         | 46  |
| warning lamps . . . . .                        | 69  |
| Air conditioning                               |     |
| air quality sensor . . . . .                   | 81  |
| rear . . . . .                                 | 84  |
| Air quality sensor . . . . .                   | 81  |
| Alarm                                          |     |
| deactivating . . . . .                         | 17  |
| Antifreeze level check . . . . .               | 203 |
| Anti-trap protection                           |     |
| windows . . . . .                              | 57  |
| Arduous driving conditions . . . . .           | 192 |
| ASL (Automatic speed limiter)                  |     |
| warning lamp . . . . .                         | 69  |

|                                       |     |
|---------------------------------------|-----|
| Audio                                 |     |
| Settings . . . . .                    | 143 |
| Audio/video                           |     |
| controls . . . . .                    | 142 |
| portable media                        |     |
| connections . . . . .                 | 156 |
| controls . . . . .                    | 154 |
| pairing . . . . .                     | 158 |
| play . . . . .                        | 158 |
| video media player                    |     |
| controls . . . . .                    | 160 |
| Automatic gearbox . . . . .           | 104 |
| Automatic locking . . . . .           | 12  |
| Automatic switch off (ACC) . . . . .  | 130 |
| Auxiliary devices                     |     |
| connecting multiple devices . . . . . | 158 |

**B**

|                                 |     |
|---------------------------------|-----|
| Battery                         |     |
| changing                        |     |
| timed climate remote . . . . .  | 232 |
| charging . . . . .              | 231 |
| jump starting                   |     |
| connecting cables . . . . .     | 228 |
| vehicle                         |     |
| removing . . . . .              | 230 |
| warning symbols . . . . .       | 228 |
| Beltminder                      |     |
| warning lamp . . . . .          | 68  |
| Belts . . . . .                 | 199 |
| seatbelt warning lamp . . . . . | 68  |

- Bluetooth . . . . . 168
  - audio . . . . . 168
  - pairing . . . . . 158
  - media . . . . . 158
  - pairing . . . . . 158
  - telephone . . . . . 169
    - compatibility . . . . . 171
    - icons . . . . . 171
    - overview . . . . . 168
    - pairing . . . . . 170
    - phonebook . . . . . 172
    - safety . . . . . 169
- Boost starting . . . . . 228
- Brakes
  - ABS warning lamp . . . . . 69
  - advanced emergency assist . . . . . 133
  - EBA (Emergency brake assist) . . . . . 114
  - EBD (Electronic brake force distribution) . . . . . 114
  - handbrake . . . . . 115
  - parking brake
    - warning lamp . . . . . 68
  - warning lamp . . . . . 67
- BSM (Blind spot monitor) . . . . . 60
- C**
  - Call volume . . . . . 172
  - Capacities . . . . . 209
  - Chairs
    - massage . . . . . 83
    - massage chairs . . . . . 83
    - restricted seat travel . . . . . 20
    - seatbelts . . . . . 199
    - warning lamp . . . . . 68
    - sitting correctly . . . . . 20
  - Changing a bulb . . . . . 195
  - Changing a fuse . . . . . 234
  - Changing the battery (timed climate) . . . . . 232
  - Charging the vehicle battery . . . . . 231
  - Cleaning
    - exterior . . . . . 197
    - interior . . . . . 198
    - leather . . . . . 199
    - parking sensors . . . . . 118
  - Climate control
    - rear . . . . . 84
  - Climate seats . . . . . 81
  - Closing the hood . . . . . 193
  - Condensation (headlamps) . . . . . 51
  - Controls
    - headlamps . . . . . 49
  - Coolant
    - checking the level . . . . . 203
    - specification . . . . . 203
    - top up . . . . . 203
  - Critical warning messages . . . . . 67
  - Cruise control
    - ACC (Adaptive cruise control) . . . . . 128
    - malfunction . . . . . 132
    - operating . . . . . 128
    - override . . . . . 130
    - resume follow mode . . . . . 130
    - resume set speed . . . . . 130
    - follow mode . . . . . 129
    - operating . . . . . 126
- D**
  - Daily checks . . . . . 192
  - Data recording . . . . . 251
  - Deselecting valet mode . . . . . 78
  - Destination entry . . . . . 178
    - search area . . . . . 178
  - Detection beam issues . . . . . 131
  - Diesel
    - engine
      - switching off . . . . . 101
  - Dimensions . . . . . 211
  - Disability modifications (air bags) . . . . . 48
  - Door transceiver
    - entry gate . . . . . 66
    - garage door opener . . . . . 64

- Drive away locking ..... 12
  - Driver controls ..... 266
  - Driver information module
    - warning lamps ..... 67
  - Driving
    - ACC (Adaptive cruise control) ... 128, 131
      - override ..... 130
    - adaptive cruise control
      - automatic switch off ..... 130
    - arduous conditions ..... 192
    - before starting ..... 251
    - controls ..... 266
    - daily checks ..... 192
    - DSC warning lamp
      - active ..... 68
      - off ..... 69
    - EBA (Emergency brake assist) ..... 114
    - EBD (Electronic brake force distribution) ... 114
    - forward alert ..... 132
      - warning lamp ..... 70
    - mirror dip when reversing ..... 59
    - sitting correctly ..... 20
    - wipers
      - rain sensor ..... 55
  - DSC (Dynamic stability control)
    - switching off ..... 108
    - switching on ..... 108
    - warning lamp
      - active ..... 68
      - off ..... 69
- E**
- EBA (Emergency brake assist) ..... 114
  - EBD (Electronic brake force distribution) 114
  - Electric seats
    - front. .... 19
    - rear ..... 23
  - Electronic brake force distribution (EBD) 114
  - Electronic data ..... 251
  - Electronic parking brake (EPB) ..... 115
  - Emergency
    - jump starting
      - connecting cables ..... 228
  - Emergency brake assist (EBA) ..... 133
  - Engine
    - compartment
      - fuse box ..... 235
      - opening ..... 193
      - overview ..... 194
    - coolant level checking ..... 203
    - engine compartment ..... 194
    - failure to start ..... 102
    - oil level check ..... 201
    - specifications ..... 208
    - switching off ..... 101
  - Entering a destination ..... 178
  - Entering the vehicle
    - entry and exit mode ..... 29
    - keyless entry ..... 11

- Entertainment
  - navigation
    - coordinates . . . . . 181
    - menu . . . . . 175
    - POI categories . . . . . 182
    - POI (Points of interest) . . . . . 180, 181
    - previous . . . . . 181
    - restore defaults . . . . . 180
    - TMC . . . . . 182
    - TMC display . . . . . 182
    - TMC icons . . . . . 183
  - portable media
    - changing device . . . . . 159
    - connecting devices . . . . . 157
    - connecting multiple devices . . . . . 158
    - connections . . . . . 156
    - controls . . . . . 154
    - lost connection . . . . . 159
    - pairing . . . . . 158
    - playing . . . . . 158
  - radio
    - controls . . . . . 148
    - RBDS (Radio broadcast data system) . . . . . 149
  - RSE (Rear screen entertainment)
    - screen settings . . . . . 77
  - satellite radio
    - controls . . . . . 151
  - telephone
    - pairing . . . . . 170
    - phonebook . . . . . 172
  - touch screen . . . . . 200
    - home menu . . . . . 76
    - operating . . . . . 77
    - setup . . . . . 77
    - system settings . . . . . 77
    - touch screen care . . . . . 77
  - video media player
    - controls . . . . . 160
- Entry and exit mode . . . . . 29
- EPB (Electric parking brake) . . . . . 115
- Event data recording . . . . . 251
- Exiting the vehicle
  - door locks and release levers . . . . . 17
  - keyless locking . . . . . 16
- Exterior cleaning . . . . . 197
- Exterior lamps
  - bulb changing . . . . . 195
- Exterior mirrors . . . . . 58
- EZ toll card . . . . . 57
- F**
  - Flat spots . . . . . 223
  - Fluids
    - capacities . . . . . 209
    - coolant
      - specification . . . . . 203
      - top up . . . . . 203
    - engine oil
      - check . . . . . 201
    - specifications . . . . . 208
    - washer
      - specification . . . . . 206
      - top up . . . . . 206
  - Fog lamps
    - warning lamp . . . . . 69
  - Follow mode . . . . . 69
    - entering . . . . . 129
    - gap change . . . . . 129
    - override . . . . . 130
    - resume . . . . . 130
  - Forward alert . . . . . 132
  - Forward alert warning lamp . . . . . 70
  - Front parking aid . . . . . 117
    - system fault . . . . . 118
  - Fuel and refuelling
    - fuel system . . . . . 193
  - Fuses
    - changing . . . . . 234
    - engine compartment fuse box . . . . . 235
    - locations . . . . . 233
    - luggage compartment fuse box . . . . . 239
    - Passenger compartment fuse box . . . . . 236

**G**

|                            |     |
|----------------------------|-----|
| Garage door opener         | 64  |
| entry gate                 | 66  |
| Gearbox                    |     |
| automatic                  | 104 |
| limp home mode             | 107 |
| temporary manual selection | 106 |
| Global opening             | 11  |

**H**

|                                           |     |
|-------------------------------------------|-----|
| Hand brake                                |     |
| warning lamp                              | 68  |
| Handbrake                                 | 115 |
| Handling                                  |     |
| DSC warning lamp                          |     |
| active                                    | 68  |
| off                                       | 69  |
| EBD (Electronic brake force distribution) | 114 |
| Headlamps                                 |     |
| adaptive                                  | 50  |
| AFS (Adaptive front lighting system)      | 50  |
| bulb changing                             | 195 |
| condensation                              | 51  |
| controls                                  | 49  |
| high beam warning lamp                    | 70  |
| warning lamp (AFS)                        | 69  |
| washers                                   | 55  |
| Heating and ventilation                   |     |
| rear                                      | 84  |
| High beam                                 |     |
| warning lamp                              | 70  |
| Homelink                                  | 64  |
| Hood                                      |     |
| closing                                   | 193 |
| opening                                   | 193 |

**I**

|                      |     |
|----------------------|-----|
| Ignition             |     |
| rolling re-start     | 102 |
| switching on         | 101 |
| Information messages | 67  |

## Infotainment

|                                    |          |
|------------------------------------|----------|
| navigation                         |          |
| coordinates                        | 181      |
| menu                               | 175      |
| POI categories                     | 182      |
| POI (Points of interest)           | 180, 181 |
| previous                           | 181      |
| restore defaults                   | 180      |
| TMC                                | 182      |
| TMC display                        | 182      |
| TMC icons                          | 183      |
| portable media                     |          |
| changing device                    | 159      |
| connecting devices                 | 157      |
| connecting multiple devices        | 158      |
| connections                        | 156      |
| controls                           | 154      |
| lost connection                    | 159      |
| pairing                            | 158      |
| playing                            | 158      |
| radio                              |          |
| controls                           | 148      |
| RBDS (Radio broadcast data system) | 149      |
| RSE (Rear seat entertainment)      |          |
| screen settings                    | 77       |
| satellite radio                    |          |
| controls                           | 151      |
| telephone                          |          |
| pairing                            | 170      |
| phonebook                          | 172      |
| touch screen                       | 200      |
| home menu                          | 76       |
| operating                          | 77       |
| setup                              | 77       |
| system settings                    | 77       |
| touch screen care                  | 77       |
| video media player                 |          |
| controls                           | 160      |
| Inhibited media playback           | 161      |
| Instrument panel                   |          |
| lamp test                          | 67       |
| warning lamps                      | 67       |

|                         |     |
|-------------------------|-----|
| Interior cleaning ..... | 198 |
| Interior lamps          |     |
| bulb changing .....     | 195 |

## J

|                     |     |
|---------------------|-----|
| Jump starting ..... | 228 |
|---------------------|-----|

## K

|                              |    |
|------------------------------|----|
| Keyless entry .....          | 11 |
| Keyless locking .....        | 16 |
| Keys                         |    |
| smart key transmitters ..... | 12 |

## L

|                                        |     |
|----------------------------------------|-----|
| Lamp test .....                        | 67  |
| Lamps                                  |     |
| bulb changing .....                    | 195 |
| condensation .....                     | 51  |
| controls .....                         | 49  |
| warning                                |     |
| parking brake .....                    | 68  |
| warning lamps .....                    | 67  |
| TPMS (Tire pressure monitoring system) |     |
| 70                                     |     |
| Leather cleaning .....                 | 199 |
| Lights                                 |     |
| bulb changing .....                    | 195 |
| condensation .....                     | 51  |
| controls .....                         | 49  |
| Limp home mode .....                   | 107 |
| Locking                                |     |
| door locks and release levers .....    | 17  |
| drive away .....                       | 12  |
| keyless .....                          | 16  |
| mislock .....                          | 17  |
| Locking and unlocking                  |     |
| unlocking .....                        | 9   |
| Lubricants                             |     |
| specifications .....                   | 208 |
| Luggage compartment                    |     |
| fuse box .....                         | 239 |

## M

|                                             |     |
|---------------------------------------------|-----|
| Maintenance                                 |     |
| blocked washer jets .....                   | 195 |
| bulb changing .....                         | 195 |
| capacities .....                            | 209 |
| changing a fuse .....                       | 234 |
| cleaning parking sensors .....              | 118 |
| closing the hood .....                      | 193 |
| coolant level checking .....                | 203 |
| daily checks .....                          | 192 |
| engine compartment .....                    | 194 |
| exterior cleaning .....                     | 197 |
| fuse box (luggage compartment) .....        | 239 |
| interior cleaning .....                     | 198 |
| jump starting                               |     |
| connecting cables .....                     | 228 |
| leather cleaning .....                      | 199 |
| lubricants and fluid specifications .....   | 208 |
| smart key battery changing .....            | 15  |
| weekly checks .....                         | 192 |
| Map (navigation system) .....               | 181 |
| Map split screen (navigations system) ..... | 177 |
| Massage seats .....                         | 83  |
| Media .....                                 | 161 |
| inhibited .....                             | 161 |
| portable                                    |     |
| lost connection .....                       | 159 |
| play .....                                  | 158 |
| portable media                              |     |
| connections .....                           | 156 |
| Messages .....                              | 67  |
| Mirrors                                     |     |
| BSM (Blind spot monitor) .....              | 60  |
| dip when reversing .....                    | 59  |
| Mirrors and windows                         |     |
| exterior mirrors .....                      | 58  |
| sunroof                                     |     |
| reset .....                                 | 196 |
| Moon roof                                   |     |
| reset .....                                 | 196 |

**N****Navigation**

|                           |     |
|---------------------------|-----|
| cancel guidance           | 180 |
| destination entry         | 178 |
| coordinates               | 181 |
| emergency                 | 181 |
| previous                  | 181 |
| search area               | 178 |
| start guidance            | 179 |
| map                       | 181 |
| map split screen          | 177 |
| menu                      | 175 |
| operating                 | 174 |
| overview                  | 173 |
| POI (Points of interest)  | 181 |
| categories/sub-categories | 182 |
| quick POI selection       | 180 |
| POI search                | 182 |
| restore defaults          | 180 |
| screen modes              | 178 |
| TMC                       | 182 |
| display                   | 182 |
| icons                     | 183 |
| using TMC                 | 184 |
| voice commands (POI)      | 167 |
| voice guidance            | 180 |

**O****Occupant safety**

|              |     |
|--------------|-----|
| seatbelts    | 199 |
| warning lamp | 68  |

**Oil**

|                          |     |
|--------------------------|-----|
| engine                   |     |
| level check              | 201 |
| engine oil specification | 202 |
| used engine oil          | 193 |

**Opening the hood** 193**Overriding speed and follow mode (cruise)** 130**P****Paddle shift**

|                            |     |
|----------------------------|-----|
| temporary manual selection | 106 |
|----------------------------|-----|

**Parking aid**

|                 |     |
|-----------------|-----|
| operating       | 117 |
| sensor cleaning | 118 |
| system fault    | 118 |

**Parking brake** 115

|              |    |
|--------------|----|
| warning lamp | 68 |
|--------------|----|

**Passenger compartment fuse box** 236**Petrol**

|               |     |
|---------------|-----|
| engine        |     |
| switching off | 101 |

**Phone**

|                            |     |
|----------------------------|-----|
| bluetooth                  | 168 |
| call volume                | 172 |
| changing connected phone   | 171 |
| compatibility              | 169 |
| controls                   |     |
| steering wheel             | 171 |
| icons                      | 171 |
| overview                   | 168 |
| pairing using touch screen | 170 |
| phonebook                  | 172 |
| safety                     | 169 |

**POI (Points of interest)** 181

|        |     |
|--------|-----|
| search | 182 |
|--------|-----|

**Portable media**

|                             |     |
|-----------------------------|-----|
| changing device             | 159 |
| connecting devices          | 157 |
| connecting multiple devices | 158 |
| connections                 | 156 |
| controls                    | 154 |
| lost connection             | 159 |
| pairing                     | 158 |
| playing                     | 158 |

**Previous destination (navigation system)** 181**Punctured tires** 223

## R

|                                              |     |
|----------------------------------------------|-----|
| Radio                                        |     |
| controls                                     | 148 |
| RBDS (Radio broadcast data system)           | 149 |
| Rain sensor                                  | 55  |
| RBDS (Radio broadcast data system)           | 149 |
| RBDS-TMC                                     | 182 |
| display                                      | 182 |
| icons                                        | 183 |
| RDS-TMC                                      | 184 |
| Rear media                                   |     |
| screen settings                              | 77  |
| Recording                                    |     |
| service data                                 | 251 |
| Recovery                                     |     |
| towing eyes                                  | 246 |
| transporting                                 | 248 |
| Remote control                               |     |
| battery changing                             | 15  |
| system transmitters                          | 213 |
| Removing vehicle battery                     | 230 |
| Replacement tires                            | 223 |
| Reporting safety defects                     | 8   |
| Resetting the windows                        | 196 |
| Restarting the engine whilst moving          | 102 |
| Restore default settings (navigation system) | 180 |
| Restricted seat travel                       | 20  |
| Resume speed and follow mode (ACC)           | 130 |
| Reverse parking aid                          | 117 |
| system fault                                 | 118 |
| Rolling re-start                             | 102 |
| RSE (Rear seat entertainment)                |     |
| screen settings                              | 77  |

## S

|                                     |     |
|-------------------------------------|-----|
| Safety                              |     |
| air bag deployment effects          | 46  |
| air bag operation                   | 44  |
| air bag service information         | 47  |
| air bags                            | 43  |
| disability modifications (air bags) | 48  |
| in the garage                       | 192 |
| seatbelts                           | 199 |
| warning lamp                        | 68  |
| sitting correctly                   | 20  |
| smart key transmitter locations     | 12  |
| used engine oil                     | 193 |
| using the telephone                 | 169 |
| Safety defects                      | 8   |
| Safety precautions                  |     |
| tire care                           | 219 |
| Satellite navigation                |     |
| cancel guidance                     | 180 |
| destination entry                   | 178 |
| coordinates                         | 181 |
| previous                            | 181 |
| search area                         | 178 |
| start guidance                      | 179 |
| emergency                           | 181 |
| map                                 | 181 |
| map split screen                    | 177 |
| menu                                | 175 |
| operating                           | 174 |
| overview                            | 173 |
| POI (Points of interest)            | 181 |
| categories                          | 182 |
| quick POI selection                 | 180 |
| POI search                          | 182 |
| restore defaults                    | 180 |
| screen modes                        | 178 |
| TMC                                 | 182 |
| display                             | 182 |
| icons                               | 183 |
| using TMC                           | 184 |
| voice commands (POI)                | 167 |
| voice guidance                      | 180 |

- Satellite radio
    - controls . . . . . 151
  - Screen modes (navigation system) . . . . . 178
  - Search area (navigation system) . . . . . 178
  - Seatbelts . . . . . 199
    - warning lamp . . . . . 68
  - Seats
    - climate . . . . . 81
    - electric
      - front . . . . . 19
      - rear . . . . . 23
    - restricted seat travel . . . . . 20
    - seat massage . . . . . 83
    - seatbelts . . . . . 199
      - warning lamp . . . . . 68
    - sitting correctly . . . . . 20
  - Security
    - deactivating the alarm . . . . . 17
  - Selecting valet mode . . . . . 78
  - Servicing
    - data recording . . . . . 251
  - Setting a destination (navigation) . . . . . 178
  - Settings
    - rear media . . . . . 77
  - Silencing the alarm . . . . . 17
  - Sitting correctly . . . . . 20
  - Smart key
    - battery changing . . . . . 15
    - transmitters . . . . . 12, 213
  - Specifications
    - dimensions . . . . . 211
    - engine . . . . . 208
    - fluids . . . . . 208
      - washer . . . . . 206
    - lubricants . . . . . 208
    - weight . . . . . 210
  - Speed-dependent wipers . . . . . 55
  - Split screen map . . . . . 177
  - SRS (Supplementary restraint system)
    - air bag covers . . . . . 199
    - air bag warning lamp . . . . . 69
    - air bags . . . . . 191
  - Stability control
    - switching off . . . . . 108
    - switching on . . . . . 108
  - Starting
    - preparation . . . . . 251
  - Starting navigation guidance . . . . . 179
  - Steering wheel
    - adjusting . . . . . 29
    - controls
      - connect phone call . . . . . 171
      - decrease volume . . . . . 171
      - disconnect phone call . . . . . 171
      - increase volume . . . . . 171
      - scroll/search down . . . . . 171
      - voice control talk . . . . . 171
  - Steering wheel controls . . . . . 171
  - Storage compartments . . . . . 94
    - cup holders . . . . . 94
    - front cubby box . . . . . 94
    - glove box . . . . . 94
    - rear armrest . . . . . 94
  - Sunroof
    - reset . . . . . 196
  - Switching off the engine . . . . . 101
  - Switching on the ignition . . . . . 101
- ## T
- Technical specifications
    - weights . . . . . 210
  - Telephone
    - bluetooth . . . . . 168
    - call volume . . . . . 172
    - changing the connected telephone . . . . . 171
    - compatibility . . . . . 169
    - controls
      - steering wheel . . . . . 171
    - icons . . . . . 171
    - overview . . . . . 168
    - pairing . . . . . 170
    - phonebook . . . . . 172
    - safety . . . . . 169

- Tires
  - flat spots . . . . . 223
  - punctured . . . . . 223
  - replacements . . . . . 223
  - tire care . . . . . 219
  - TPMS (Tire pressure monitoring system)
    - warning lamp . . . . . 70
  - valves . . . . . 223
- TMC . . . . . 182
  - display . . . . . 182
  - icons . . . . . 183
- TMC (Traffic message channel) . . . . . 184
- Toll card fixing . . . . . 57
- Touch screen . . . . . 200
  - home menu . . . . . 76
  - navigation
    - coordinates . . . . . 181
    - menu . . . . . 175
    - POI categories . . . . . 182
    - POI (Points of interest) . . . . . 180, 181
    - screen modes . . . . . 178
    - search area . . . . . 178
    - TMC . . . . . 182
    - TMC icons . . . . . 183
  - operating . . . . . 77
  - portable media
    - changing device . . . . . 159
    - connecting devices . . . . . 157
    - connecting multiple devices . . . . . 158
    - connections . . . . . 156
    - controls . . . . . 154
    - lost connection . . . . . 159
    - pairing . . . . . 158
    - playing . . . . . 158
  - RSE (Rear seat entertainment)
    - screen settings . . . . . 77
  - setup . . . . . 77
  - system settings . . . . . 77
  - telephone
    - pairing . . . . . 170
    - phonebook . . . . . 172
  - touch screen care . . . . . 77
  - valet mode . . . . . 78
  - video media player
    - controls . . . . . 160
- Towing eyes . . . . . 246
- TPMS (Tire pressure monitoring system)
  - tire care . . . . . 219
  - valves . . . . . 223
  - warning lamp . . . . . 70
- Traction control
  - switching off . . . . . 108
  - switching on . . . . . 108
- Transmission
  - limp home mode . . . . . 107
  - temporary manual selection . . . . . 106

- Transmission (automatic) . . . . . 104
- Transmitters
  - smart key. . . . . 12, 213
- Transporting the vehicle . . . . . 248
- Trim
  - air bag covers (cleaning) . . . . . 199
- U**
- Unlocking . . . . . 9, 17
  - entry and exit mode. . . . . 29
  - global opening. . . . . 11
  - keyless entry . . . . . 11
- Used engine oil . . . . . 193
- Using cruise control . . . . . 126
- Using the parking aid. . . . . 117
- V**
- Valet mode . . . . . 78
  - deselecting . . . . . 78
- Vehicle battery
  - jump starting
    - connecting cables . . . . . 228
    - removing . . . . . 230
- Vehicle cleaning
  - exterior . . . . . 197
  - interior. . . . . 198
  - parking sensors. . . . . 118
- Vehicle data recording. . . . . 251
- Vehicle recovery
  - towing eyes . . . . . 246
  - transporting the vehicle . . . . . 248
- Vehicle settings
  - valet mode. . . . . 78
- Video media player
  - controls. . . . . 160
  - inhibited playback . . . . . 161
- Voice control . . . . . 165
  - navigation POI. . . . . 167
  - training . . . . . 166
  - tutorial . . . . . 166
  - voicetags . . . . . 167
- Voice guidance . . . . . 180
- Volume
  - telephone . . . . . 172
- W**
- Warning lamps . . . . . 67
  - ABS. . . . . 69
  - adaptive front lighting system. . . . . 69
  - AFS . . . . . 69
  - air bag. . . . . 46
  - air bags. . . . . 69
  - ASL (Automatic speed limiter) . . . . . 69
  - brake. . . . . 67
  - Critical warning message . . . . . 67
  - DSC. . . . . 68, 69
  - fog lamps . . . . . 69
  - forward alert . . . . . 70
  - headlamp high beam. . . . . 70
  - lamp test. . . . . 67
  - parking brake . . . . . 68
  - seatbelt . . . . . 68
  - TPMS (Tire pressure monitoring system) . . . . . 70
- Warning symbols (battery). . . . . 228
- Warranty. . . . . 187
- Washer jets
  - blockages . . . . . 195
- Washers
  - operating. . . . . 54
- Washers (headlamps). . . . . 55
- Weekly checks . . . . . 192
- Weights . . . . . 210
- Wheel and tires
  - replacements . . . . . 223
  - TPMS (Tire pressure monitoring system)
    - warning lamp . . . . . 70
- Wheels and tires
  - flat spots. . . . . 223
  - punctured . . . . . 223
  - tire care. . . . . 219
  - valves . . . . . 223

|                            |     |
|----------------------------|-----|
| Windows .....              | 56  |
| anti-trap protection ..... | 57  |
| reset .....                | 196 |
| sunroof                    |     |
| reset. ....                | 196 |
| Windscreen wipers          |     |
| speed-dependent mode ..... | 55  |
| Wipers                     |     |
| operating .....            | 54  |
| Wipers and washers         |     |
| fluid                      |     |
| specification. ....        | 206 |
| top up .....               | 206 |
| operating .....            | 54  |
| rain sensor. ....          | 55  |
| wipers                     |     |
| speed-dependent mode ..... | 55  |

