

A	
About this handbook.....	2
Access height (air suspension).....	109
Accessories.....	199
Access to rear seats.....	21
Adaptive dynamics.....	110
Adaptive front lighting system.....	54
warning lamp.....	51
Adaptive headlamps.....	54
Age degradation (tyres).....	237
Airbags	
curtain.....	42
deployment.....	40, 42
disability modifications.....	44
disabling.....	42
front.....	42
locations.....	40
maintenance.....	199
module covers.....	213
service information.....	43
side.....	42
warning lamp.....	42, 51
Air conditioning	
automatic recirculation.....	76
front.....	75
rear.....	79
remote control batteries.....	79
using the remote control.....	78
Air quality sensor.....	76
Air suspension.....	108
access height.....	109
adaptive dynamics.....	110
DSC fault safety override.....	110
extended mode.....	109
locked access height.....	109
off-road height.....	108
remote operation.....	109
safety override lowering height.....	110
Alarm.....	13, 199
deactivating.....	16
interior disabling.....	14
perimeter.....	13
Anchor points (ISOFIX).....	36
Anchor points (luggage).....	87
Anti-lock braking system (ABS) warning lamp.....	51
Anti-theft system.....	199
Arduous driving conditions.....	200
Audio	
automatic station retune.....	148
CD loading.....	142
changing portable media device.....	157
connecting portable media devices.....	154
DAB radio	
controls.....	149
settings.....	150
stations.....	150
DAB radio controls.....	149
dual view.....	162
dual view controls.....	162
DVD player controls.....	160
full screen view.....	161
license agreements.....	145
portable media connections.....	154
portable media controls.....	152
portable media pairing.....	156
portable media playing.....	155
radio controls.....	147
rear media touch screen control.....	164
sound settings.....	142
touch screen controls.....	141
TV controls.....	158
video player controls.....	160
Automatic locking.....	8
Automatic recirculation.....	76
Automatic speed limiter	
warning lamp.....	51
Automatic transmission.....	102
gear shift warning lamp.....	52
hill descent.....	104
range change indicators.....	104
shift paddles.....	103
stationary range changing.....	104
temporary manual selection.....	103
Auto zoom (navigation).....	180
Auxiliary device connection.....	155
Auxiliary heater.....	77

B

Battery	
boost starting.....	221
changing	
timed climate remote.....	222
charging.....	222
connecting jump leads.....	220
monitoring system.....	222
using a starting aid.....	221
Battery charge warning lamp.....	50
Battery monitoring system.....	222
Belts.....	212
Blind spot monitor	
notification of overtaking vehicle.....	63
Bluetooth	
compatibility.....	172
pairing	
via the phone.....	172
portable media	
pairing.....	156
playing.....	155
telephone.....	171
icons.....	173
overview.....	171
phonebook.....	175
safety.....	172
Bonnet	
closing.....	202
opening.....	202
Booster seats for larger children.....	39
Boost starting.....	221
Brakes	
ABS warning lamp.....	51
control with ABS.....	111
electronic brake force distribution.....	111
emergency brake assist.....	111
fluid check.....	217
fluid specification.....	218
fluid top up.....	218
handbrake.....	112
hill start assist.....	111
important information.....	111
parking brake warning lamp.....	50

pedal travel.....	264
steep slope control.....	111
warning lamp.....	49–50
Brake temperature.....	136
Bulbs	
changing a bulb.....	204
direction indicator.....	207
halogen.....	206
rear fog lamp.....	208
rear lamp.....	208
rear lamps.....	207

C

Call volume.....	174
Cameras	
proximity view.....	139
rear camera.....	115, 118
reverse traffic detection.....	116
touch screen menu.....	139
trailer guidance.....	140
Capacities.....	259
CD player	
CD loading.....	142
portable media pairing.....	156
portable media playing.....	155
Change a connected phone.....	173
Changing a bulb.....	204
Changing a fuse.....	224
Changing a wheel	
locking wheel nuts.....	247
recommended process.....	247
safety warnings.....	245
spare wheel.....	245
temporary spare wheel.....	246
tool kit.....	245
Changing the battery (timed climate).....	222
Charging the vehicle battery.....	222
Child safety	
booster seats.....	39
check list.....	34
ISOFIX anchor points.....	36
larger children.....	39
lock and window inhibitor.....	33

positioning.....	35	Cruise control.....	125
recommended child seats.....	35	warning lamp.....	52
tether straps.....	38		
Child safety tether straps.....	38	D	
Child seats.....	33	DAB radio	
Cleaning		controls.....	149
after off-road driving.....	211	ensembles.....	150
exterior.....	210	settings.....	150
exterior paintwork.....	211	DAB radio controls.....	149
interior.....	212	Data recording.....	255
leather.....	212	Daytime running lamps.....	53
paintwork with white spirit.....	210	Dealer locations.....	185
parking sensors.....	115	Declarations of conformity.....	268
seat belts.....	212	navigation system.....	192
touch screen.....	213	Deselecting valet mode.....	74
Climate control		Destination entry.....	181
automatic recirculation.....	76	postcode.....	184
front.....	75	search area.....	181
fuel burning heater.....	77	Diesel	
heated and cooled seats.....	76	filler flap.....	195
rear.....	79	emergency release.....	195
remote control batteries.....	79	fuel.....	194
timed climate.....	77	fuel tank capacity.....	196
timed climate remote controls.....	79	glow plugs	
using the remote control.....	78	warning lamp.....	50
Climate seats.....	76	misfuel device.....	197
Clock.....	45	specification.....	196
Closing the bonnet.....	202	sulphur content.....	194
Cold weather driving		water in fuel.....	196
diesel particulate filter (DPF).....	201	Diesel particulate filter	
Compact disc.....	142	sulphur content.....	194
Condensation (headlamps).....	55	Diesel particulate filter (DPF).....	200
Conformity declarations.....	192, 268	cold weather driving.....	201
Connecting jump leads.....	220	driving short distances.....	201
Convenience mode.....	8	Dimensions.....	261
Coolant		Direction indicators.....	53
checking the level.....	216	warning lamp.....	52
specification.....	216	Door mirrors.....	61
top up.....	216	blind spot monitor.....	63
Courtesy delay.....	54	Door transceiver	
Covers		assistance.....	69
refitting.....	203	garage door opener.....	67
removal.....	202	programming.....	67
Critical warning messages.....	49		

programming a single button.....	68
programming the garage door opener.....	67
rolling code device programming.....	68
Double locking.....	13
full alarm.....	13
Drive away locking.....	8
Driving	
activating intelligent stop/start.....	100
after a collision.....	255
arduous conditions.....	200
before starting.....	255
blind spot monitor.....	63
brake control with ABS.....	111
brakes important information.....	111
daily checks.....	199
deactivating intelligent stop/start.....	100
DSC active warning lamp.....	50
dynamic mode.....	106
electronic brake force distribution.....	111
emergency brake assist.....	111
forward alert warning lamp.....	52
gear shift warning lamp.....	52
hill start assist.....	111
low oil pressure.....	49
park assist limitations.....	122
park assist troubleshooting.....	122
rain sensor.....	59
sitting correctly.....	18
steep slope control with ABS.....	111
using cruise control.....	125
weekly checks.....	199
Driving abroad	
beam pattern.....	55
headlamps.....	55
Driving short distances	
diesel particulate filter (DPF).....	201
Dual view.....	162
controls.....	162
Dynamic mode.....	106
Dynamic response	
fluid level.....	219
fluid specification.....	219
fluid top up.....	219

Dynamic stability control (DSC)	
DSC active warning lamp.....	50
DSC off warning lamp.....	50
switching off.....	106
switching on.....	106

E

Easy route.....	182
Electric parking brake.....	112
Electric seats.....	17
access to rear.....	21
folding armrest.....	19
head restraint removal.....	25
head restraints.....	25
passenger seat away.....	20
seat position memory.....	19
sitting correctly.....	18
Electric windows	
operation.....	70
Electronic brake force distribution.....	111
Electronic data.....	255
Emergency (navigation).....	184
Emergency brake assist.....	111
Engine	
antifreeze level.....	216
compartment opening.....	202
coolant level.....	216
diesel fuel.....	194
diesel particulate filter (DPF).....	200
oil level.....	214
petrol fuels.....	193
specifications.....	257
Engine/transmission warning lamp.....	50
Engine compartment	
fluid filler locations.....	214
poisonous fluids.....	202
Engine covers	
refitting.....	203
removal.....	202
Engine temperature warning lamp.....	49
Entering a destination.....	181
Entering the vehicle	
entry and exit mode.....	27

global opening.....	8	coolant	
keyless entry.....	8	specification.....	216
unlocking mode.....	7	top up.....	216
unlocking the steering column.....	28	dynamic response.....	219
Entertainment		check.....	219
portable media controls.....	152	specification.....	219
Ethanol.....	193	engine oil check.....	214
EU conformity (navigation system).....	192	filler locations.....	214
Event data recording.....	255	specifications.....	257
Exiting the vehicle		washer fluid.....	218
closing mislock.....	16	check.....	218
door locks and release levers.....	15	specification.....	218
double locking.....	13	Fog lamps	
full alarm.....	13	warning lamps	
global closing.....	14	front.....	51
interior locks.....	15	rear.....	51
keyless locking.....	14	Forward alert warning lamp.....	52
perimeter alarm.....	13	Front airbags.....	42
single locking.....	13	Front climate control.....	75
Extended mode (air suspension).....	109	automatic recirculation.....	76
Exterior cleaning.....	210	Front parking aids.....	114
Exterior lamps		system fault.....	115
bulb changing.....	204	Front wipers.....	58
Exterior mirrors		winter park position.....	210
electric.....	61	Fuel and refuelling.....	195
manual.....	61	consumption.....	198
mirror dip when reversing.....	62	diesel.....	194
External temperature		diesel fuel sulphur content.....	194
warning lamp.....	51	ethanol.....	193
Extra features.....	74	filler flap.....	195
		fuel specification.....	196
		methanol.....	194
		Methyl tertiary butyl ether (MTBE).....	194
		misfuel device.....	197
		octane rating.....	193
		petrol.....	193
		reformulated gasoline.....	194
		running out.....	195
		safety precautions.....	193
		tank capacity.....	196
		water in fuel.....	196
		Fuel burning heater.....	77
		Fuel consumption.....	198
		combined cycles.....	198
F			
Favourite locations			
navigation.....	183		
navigation details.....	183		
Flat spots.....	237		
Fluids			
brake			
check.....	217		
specification.....	218		
top up.....	218		
capacities.....	259		

extra-urban cycle.....	198
urban cycle.....	198
Fuel gauge.....	45
Full screen view for video.....	161
Fuses	
changing.....	224
engine compartment fuse box.....	224
locations.....	223
luggage compartment fuse box.....	229
passenger compartment fuse box.....	226

G

Garage door opener.....	67
assistance.....	69
entry gate.....	69
programming.....	67
programming a rolling code device.....	68
programming a single button.....	68
Gearbox	
automatic.....	102
gear shift warning lamp.....	52
hill descent.....	104
limp home mode.....	105
range change indicators.....	104
range changing.....	104
stationary range changing.....	104
General program.....	133
Global closing.....	14
Global opening.....	8
Glow plugs	
warning lamp.....	50
Grass/gravel/snow.....	133

H

Handbook symbols.....	2
Handbrake.....	112
Hands free parking.....	119
park assist limitations.....	122
park assist troubleshooting.....	122
Headlamps.....	53
adaptive.....	54
beam pattern.....	55

bulb changing.....	204
condensation.....	55
courtesy delay.....	54
daytime running lamps.....	53
driving abroad.....	55
high beam assist.....	54
high beam assist warning lamp.....	52
high beam warning lamp.....	51
removal.....	204
warning lamp (AFS).....	51
washers.....	59
xenon.....	206
Head restraints.....	25
electric seats.....	25
Heated steering wheel.....	27
Heating and ventilation	
automatic recirculation.....	76
front.....	75
fuel burning heater.....	77
heated and cooled seats.....	76
rear.....	79
remote control batteries.....	79
timed climate.....	77
timed climate remote controls.....	79
using the remote control.....	78
High beam assist.....	54
Hill descent control.....	135
brake temperature.....	136
warning lamp.....	52
warning messages.....	136
Hill start assist.....	111
Home (navigation).....	183
Homelink.....	67
assistance.....	69
gate/door opener.....	69
programming.....	67
programming a single button.....	68
programming the garage door opener.....	67
rolling code device programming.....	68

I

Indicators warning lamp.....	52
Information messages.....	49

Infotainment	
automatic station retune.....	148
CD loading.....	142
DAB radio.....	149
settings.....	150
stations.....	150
dual view.....	162
controls.....	162
full screen view.....	161
license agreements.....	145
media player controls.....	160
portable media	
changing.....	157
connecting devices.....	154
connecting multiple devices.....	155
connections.....	154
controls.....	152
pairing.....	156
playing.....	155
power sockets.....	83
radio controls.....	147
rear media touch screen control.....	164
rear media use.....	166
sound settings.....	142
touch screen	
audio/video controls.....	141
care.....	73
cleaning.....	213
extra features.....	74
home menu.....	72
operating.....	73
settings.....	73
setup.....	73
TV controls.....	158
Instrument panel.....	45
display units.....	48
fuel range.....	48
lamp test.....	49
menu.....	46
driving features.....	46
instrument display.....	46
trip computer.....	46
vehicle set-up.....	46
service indicator.....	48
warning lamps.....	49
warning messages.....	46
Intelligent stop/start	
activating.....	100
deactivating.....	100
Intelligent stop/start warning lamp.....	52
Interior cleaning.....	212
Interior lamps	
ambient lighting.....	57
bulb changing.....	204
intensity.....	57
locations.....	56
stealth mode.....	57
types.....	56
Interior locking.....	15
Interior protection	
temporary disabling.....	14
ISOFIX anchor points.....	36
J	
Jump starting	
connecting a starting aid.....	221
connecting jump leads.....	220
K	
Keyless entry.....	8
Keyless locking.....	14
L	
Lamps.....	53
bulb changing.....	204
condensation.....	55
rear lamp removal.....	207
test.....	49
warning lamps.....	49
xenon headlamps.....	206
Leather cleaning.....	212
Lighting	
ambient lighting.....	57
interior lamps intensity.....	57

- interior lamps locations.....56
 - stealth mode.....57
 - Limp home mode.....105
 - Load carrying
 - luggage divider.....87
 - Load securing.....87
 - Loadspace cover.....86
 - Locked access height.....109
 - Locking
 - door locks and release levers.....15
 - double locking.....13
 - drive away.....8
 - global closing.....14
 - keyless.....14
 - mislock.....16
 - single.....13
 - Locking wheel nuts.....247
 - Low fuel warning lamp.....51
 - Low oil pressure warning lamp.....49
 - Low range gearbox
 - selecting high range on the move.....104
 - Low range transmission warning lamp.....52
 - Lubricants specifications.....257
 - Luggage compartment
 - anchor points.....87
 - divider and rails.....87
 - loadspace cover.....86
- ## M
- Maintenance
 - after-off road driving.....211
 - arduous driving conditions.....200
 - brake fluid level.....217
 - bulb changing.....204
 - rear lamp removal.....207
 - capacities.....259
 - changing a fuse.....224
 - checking tyre pressure after a repair.....243
 - cleaning
 - exterior.....210
 - interior.....212
 - leather.....212
 - parking sensors.....115
 - seat belts.....212
 - closing the bonnet.....202
 - daily checks.....199
 - diesel particulate filter (DPF).....200
 - dynamic response fluid level.....219
 - engine compartment fuse box.....224
 - engine coolant level.....216
 - engine oil level.....214
 - fuse box (passenger compartment).....226
 - jump starting.....221
 - lubricants and fluid specifications.....257
 - luggage compartment fuse box.....229
 - smart key battery.....11
 - tyre repair kit.....241
 - tyre repair procedure.....242
 - using a starting aid.....221
 - washer fluid level.....218
 - weekly checks.....199
 - Manual seats
 - folding armrest.....19
 - head restraint removal.....25
 - head restraints.....25
 - sitting correctly.....18
 - Map.....184
 - auto zoom.....180
 - split screen.....179
 - Memory seats.....19
 - Message centre display units.....48
 - Methanol.....194
 - Mirrors
 - blind spot monitor.....63
 - dip when reversing.....62
 - exterior mirrors.....61
 - Misfuel device.....197
 - Motorway entry/exit
 - route setting.....184
 - Mounting point dimensions
 - for powered tow bar.....95
 - for tow ball with multi height plate.....93
 - Mpg.....198
 - Mud ruts.....133

N

Navigation

Arabic language.....	186
automatic route learning.....	182
avoid points.....	182
destination entry.....	181
search area.....	181
destination entry by postcode.....	184
easy route.....	182
emergency contacts.....	184
favourite locations.....	183
home location.....	183
legals.....	189–192
map.....	184
auto zoom.....	180
split screen.....	179
menu.....	177
motorway entry/exit selection.....	184
off-road	
new route.....	188
route options.....	188
routes.....	188
selecting compass view.....	189
using a stored route.....	188
operating.....	176
overview.....	176
points of interest (POI).....	185
categories/sub-categories.....	185
search.....	185
previous destinations.....	184
quick POI selection.....	183
restore defaults.....	183
screen modes.....	181
Start guidance.....	182
TMC.....	186, 188
display.....	186
icons.....	187
voice commands.....	169
voice guidance.....	183

O

Occupant safety

child seat tether straps.....	38
recommended child seats.....	35
seat belt pre-tensioners.....	31
seat belt reminder warning.....	31
seatbelts.....	212
seat belt safety.....	30
seatbelts warning lamp.....	50
using seat belts.....	29

Octane rating.....	193
petrol engines.....	193

Off-road driving

dynamic program.....	134
general program.....	133
grass/gravel snow.....	133
mud ruts.....	133
override options.....	134
rock crawl program.....	134
sand program.....	133

Off-road height

air suspension.....	108
---------------------	-----

Off-road navigation

new route.....	188
route options.....	188
selecting compass view.....	189
using a stored route.....	188

Oil

used engine oil.....	202
----------------------	-----

Oils

filler locations.....	214
poisonous fluids.....	202

Oil specification.....	257
------------------------	-----

Opening

bonnet.....	202
-------------	-----

Owner maintenance.....	199
------------------------	-----

P

Paddle shift

temporary manual selection.....	103
---------------------------------	-----

Paintwork

cleaning.....	211
---------------	-----

- Pairing
 - via the phone.....172
 - Park assist
 - limitations of use.....122
 - troubleshooting.....122
 - Parking
 - hands free parking.....119
 - park assist limitations.....122
 - park assist troubleshooting.....122
 - Parking aid
 - sensor cleaning.....115
 - Parking aids
 - operating.....114
 - rear camera.....115, 118
 - reverse traffic detection.....116
 - system fault.....115
 - Parking brake.....112
 - warning lamp.....50
 - Parts.....199
 - Passenger compartment fuse box.....226
 - Passenger seat away
 - control from rear.....20
 - Perimeter alarm.....13
 - Petrol
 - fuel tank capacity.....196
 - octane rating.....193
 - specification.....196
 - Petrol consumption.....198
 - Petrol engines
 - fuel types.....193
 - Petrol filler flap.....195
 - emergency release.....195
 - Phone
 - Bluetooth compatibility.....172
 - call volume.....174
 - change the phone.....173
 - controls
 - steering wheel controls.....174
 - icons.....173
 - overview.....171
 - pairing via the phone.....172
 - phonebook.....175
 - safety.....172
 - Phonebook.....175
 - Points of interest (POI).....185
 - navigation.....185
 - search.....185
 - Portable media
 - changing device.....157
 - connecting devices.....154
 - connecting multiple devices.....155
 - connections.....154
 - controls.....152
 - pairing.....156
 - playing.....155
 - power sockets.....83
 - Postcode
 - destination entry.....184
 - Powered tailgate
 - opening height.....11
 - Powered tow bar.....91
 - Power sockets
 - centre console.....83
 - cubby box.....83
 - luggage area.....83
 - Pressure checking (tyres)
 - checking after a repair.....243
 - Pressures
 - tyres.....235
 - Previous destinations (navigation system).....184
 - Programming the timed climate.....77
 - Puncture repair kit.....241
 - instructions for use.....242
 - repair procedure.....242
 - safety.....241
- ## Q
- Quick POI
 - selection.....183
- ## R
- Radio
 - automatic station retune.....148
 - controls.....147

- DAB
 - controls.....149
 - settings.....150
- DAB controls.....149
- DAB stations.....150
- Radio data system
 - auto retune.....148
- Rain sensor.....59
- Range change indicators.....104
- Range changing
 - indicators.....104
 - while stationary.....104
- RDS-TMC.....188
 - display.....186
 - icons.....187
- RDS-TMC overview.....186
- Rear camera
 - parking aids.....115–116, 118
- Rear climate control.....79
- Rear fog lamps
 - warning lamp.....51
- Rear lamp
 - bulb changing.....207
 - removal.....207
- Rear media
 - remote control batteries.....167
 - remote control use.....165–166
 - touch screen control.....164
- Rear seat entertainment
 - remote control batteries.....167
 - remote control use.....165–166
 - touch screen control.....164
- Rear seats
 - access.....21
 - folding and raising.....21
 - manual adjustment.....20
 - passenger seat away.....20
 - third row folding and raising.....22
- Recording
 - service data.....255
- Recovery
 - towing eyes.....251
 - towing on four wheels.....253
 - transporting.....253
- Reformulated gasoline.....194
- Refuelling
 - diesel.....194
 - diesel fuel sulphur content.....194
 - ethanol.....193
 - methanol.....194
 - MTBE.....194
 - octane rating.....193
 - petrol.....193
 - reformulated gasoline.....194
 - running out of fuel.....195
 - safety precautions.....193
- Reminder
 - seat belt unbuckled warning.....31
- Remote control
 - rear media.....165–166
 - single locking.....13
 - smart key battery.....11
- Remote control batteries
 - rear media.....167
- Remote operation
 - air suspension.....109
- Removing a head restraint.....25
- Removing the spare wheel.....245
- Replacement tyres.....236
- Resetting the windows.....210
- Restore navigation default settings.....183
- Reverse parking aids.....114
 - rear camera.....118
 - reverse traffic detection.....116
 - system fault.....115
- Reverse traffic detection.....116
- Rock crawl program.....134
- Rolling road
 - vehicle testing.....201
- Route
 - favourite locations.....183
 - favourites details.....183
- Running out of fuel.....195

S

- Safety
 - fuel and refuelling.....193

- seat belt pre-tensioners.....31
- seat belt reminder warning.....31
- seatbelts.....212
- seat belts.....30
- seatbelts warning lamp.....50
- sitting correctly.....18
- tyre care.....234
- tyre pressures.....235
- used engine oil.....202
- using seat belts.....29
- using the telephone.....172
- Safety in the garage
 - battery precautions.....201
 - electrical components.....201
 - engine fans.....201
 - exhaust gases.....201
 - hot components.....201
 - jacking.....201
- Safety locks.....33
- Safety seats for larger children.....39
- Sand program.....133
- Satellite navigation
 - Arabic language.....186
 - automatic route learning.....182
 - avoid points.....182
 - cancel guidance.....183
 - compass view.....189
 - coordinates entry.....184
 - dealer locations.....185
 - destination entry.....181
 - search area.....181
 - destination entry by postcode.....184
 - easy route.....182
 - emergency contacts.....184
 - favourite locations.....183
 - home location.....183
 - legals.....189–192
 - map.....184
 - auto zoom.....180
 - split screen.....179
 - menu.....177
 - motorway entry/exit selection.....184
 - off-road
 - route entry.....188
 - route options.....188
 - routes.....188
 - operating.....176
 - overview.....176
 - points of interest (POI).....185
 - categories.....185
 - search.....185
 - previous destinations.....184
 - quick POI selection.....183
 - restore defaults.....183
 - screen modes.....181
 - Start guidance.....182
 - stored route loading.....188
 - TMC.....186, 188
 - display.....186
 - icons.....187
 - voice commands.....169
 - voice guidance.....183
- Screen modes (navigation).....181
- Screen settings
 - screensaver.....73
 - theme.....73
 - time out period.....73
 - volume pop-up.....73
- Screen wash
 - fluid level.....218
- Search area (navigation).....181
- Seatbelts.....212
- Seat belts
 - adjusting.....29
 - checks.....30
 - pre-tensioners.....31
 - reminder warning.....31
 - safety.....30
 - use.....29
 - warning lamp.....50
- Seat position memory.....19
- Seats
 - child restraint check list.....34
 - child seat positioning.....35
 - child seats.....33
 - child seat tether straps.....38
 - climate.....76
 - electric front.....17

electric head restraints.....	25	dimensions.....	261
folding armrest.....	19	engine.....	257
head restraint removal.....	25	ethanol.....	193
head restraints.....	25	fluids.....	257
rear control of front passenger seat.....	20	fuel.....	196
rear seat access.....	21	Fuel tank capacity.....	196
rear seat adjustments.....	20	lubricants.....	257
rear seat folding.....	22	methanol.....	194
rear seat folding and raising.....	21	MTBE.....	194
recommended child seats.....	35	weight.....	260
seatbelts.....	212	wheel alignment.....	263
seatbelts warning lamp.....	50	wheels and tyres.....	262
seat position memory.....	19	Speed-dependent wipers.....	59
sitting correctly.....	18	Speedometer.....	45
Securing luggage		Split screen map.....	179
anchor points.....	87	SRS	
Security.....	13	airbag warning lamp.....	51
alarm.....	199	Stability control.....	106
closing mislock.....	16	switching off.....	106
deactivating the alarm.....	16	switching on.....	106
perimeter alarm.....	13	Starting after a collision.....	255
single locking.....	13	Start navigation guidance.....	182
Selecting valet mode.....	74	Stationary range changing.....	104
Service information		Stealth mode.....	57
airbags.....	43	Steering column	
Servicing		locking.....	8
data recording.....	255	selecting AUTO position.....	27
Setting a timed climate program.....	77	vehicle recovery.....	8
Settings menu.....	46	Steering column lock.....	28
display units.....	48	Steering wheel	
Side lamps		adjusting.....	27
warning lamps.....	52	heated.....	27
Silencing the alarm.....	16	Steering wheel controls	
Sitting correctly.....	18	telephone.....	174
Smart key		Stop/start	
battery changing.....	11	activating.....	100
single locking.....	13	deactivating.....	100
Snow chains.....	238	Storage compartments.....	82
Sound settings		cup holders.....	82
audio system.....	142	front cubby box.....	82
Spare wheel.....	245	rear armrest.....	82
using wheel chocks.....	246	Storage compartments areas	
Specifications		glove box.....	82
brake pedal travel.....	264		

- Sunroof
 - reset.....210
 - Supplementary restraint system
 - airbag covers.....213
 - airbag deployment.....42
 - airbag locations.....40
 - airbags maintenance.....199
 - airbag warning lamp.....42
 - curtain airbags.....42
 - front airbags.....42
 - Supplementary restraint system (SRS)
 - airbag warning lamp.....51
 - side airbags.....42
 - Surround cameras
 - touch screen menu.....139
 - trailer guidance.....140
 - Suspension
 - access height.....109
 - adaptive dynamics.....110
 - air suspension.....108
 - extended mode.....109
 - height adjustment.....108
 - locked access height.....109
 - off-road height.....108
 - remote operation.....109
 - safety override lowering height.....110
 - Symbols used in this handbook.....2
- T**
- Tachometer.....45
 - Tailgate
 - opening and closing.....9
 - powered opening height.....11
 - Technical specifications
 - weights.....260
 - wheel alignment.....263
 - wheels and tyres.....262
 - Telephone
 - Bluetooth compatibility.....172
 - call volume.....174
 - change the phone.....173
 - compatibility list.....172
 - hands free operation.....171
 - icons.....173
 - overview.....171
 - pairing
 - via the phone.....172
 - phonebook.....175
 - safety.....172
 - steering wheel controls.....174
 - Television
 - controls.....158
 - Terrain response
 - controls.....133
 - general program.....133
 - grass/gravel snow.....133
 - mud ruts.....133
 - override options.....134
 - program selections.....133
 - rock crawl program.....134
 - sand program.....133
 - system difficulties.....134
 - Tilt sensor.....247
 - Timed climate.....77
 - additional remote controls.....79
 - programming.....77
 - remote control batteries.....79
 - using the remote control.....78
 - Tires
 - important information.....250
 - use of spare tire.....250
 - Tool kit.....245
 - Touch screen.....213
 - 4x4i menu.....137
 - audio/video controls.....141
 - automatic recirculation.....76
 - button feedback.....73
 - changing portable media device.....157
 - clock.....73
 - connecting multiple portable media devices.....155
 - connecting portable media devices.....154
 - DAB radio controls.....149
 - dual view.....162
 - dual view controls.....162
 - DVD player controls.....160
 - extra features.....74

front climate control.....	75	levelling.....	90
fuel burning heater.....	77	lights.....	90
heated and cooled seats.....	76	nose weight limit.....	90
home menu.....	72	tow ball.....	90
inhibited display.....	161	tyre pressures.....	90
language selection.....	73	Towing eyes.....	251
license agreements.....	145	Towing weights	
operating.....	73	maximum weights.....	89
portable media.....	152	Traction control	
controls.....	152	switching off.....	106
portable media connections.....	154	switching on.....	106
portable media pairing.....	156	Traffic message channel (TMC).....	188
portable media playing.....	155	Trailer direction indicators green warning	
radio controls.....	147	lamp.....	52
screen settings.....	73	Trailer electrical connections.....	89
setup.....	73	Trailer guidance	
shortcuts.....	73	cameras.....	140
surround cameras menu.....	139	Trailer sway.....	90
system settings.....	73	Trailer weights	
telephone.....	175	maximum weights.....	89
phonebook.....	175	Transfer gearbox	
touch screen care.....	73	range changing on the move.....	104
TV controls.....	158	Transmission	
valet mode.....	74	automatic.....	102
video player controls.....	160	gear shift warning lamp.....	52
volume presets.....	73	hill descent.....	104
Tow ball		limp home mode.....	105
mounting point dimensions.....	93	range change indicators.....	104
multi-height drop plate.....	93	range changing.....	104
powered tow bar.....	91	stationary range changing.....	104
Tow bar		Transporting the vehicle.....	253
mounting point dimensions.....	95	Trim	
Towing		airbag covers (cleaning).....	213
mounting point dimensions.....	93, 95	Trip computer.....	47
multi-height drop plate.....	93	average speed.....	47
powered tow bar.....	91	fuel consumption.....	47
stability assist.....	90	fuel range.....	48
trailer electrical connections.....	89	reset.....	47
trailer sway.....	90	trip distance.....	47
Towing a trailer.....	90	TV	
Towing checks		controls.....	158
breakaway cable.....	90	dual view.....	162
calculating weight.....	90	dual view controls.....	162
essential checks.....	90	Tyre pressure checking after a repair.....	243

Tyre pressure monitoring system.....	239	steering column.....	28
full size replacements.....	240	USB devices	
valves.....	236	connecting multiple devices.....	155
Tyre pressure monitoring system (TPMS)		Used engine oil.....	202
tyre care.....	234	Using cruise control.....	125
Tyre repair kit		Using the parking aids.....	114
repair procedure.....	242	Using the spare tire	
Tyres		important information.....	250
age degradation.....	237	Using wheel chocks.....	246
changing.....	240		
flat spots.....	237		
full size replacements.....	240		
Indian regulations.....	238		
pressures.....	235		
repair kit.....	241		
repair kit use.....	242		
repair procedure.....	242		
replacements.....	236		
snow chains.....	238		
speed ratings.....	234		
temporary use spare.....	240		
TPMS.....	239		
tyre care.....	234		
tyre repair safety.....	241		
tyre wall markings.....	233		
valves.....	236		
winter.....	237		
Tyre speed ratings.....	234		
Tyre valves.....	236		
Tyre wall markings.....	233		

U

Under bonnet covers.....	202–203
Unlocking.....	15
all doors.....	5
driver's door.....	5
entry and exit mode.....	27
global opening.....	5, 8
keyless entry.....	8
mode.....	5
multi point entry.....	5, 7
opening the tailgate.....	9
single point entry.....	5, 7

V

Valet mode.....	74
deactivation.....	5
deselecting.....	74
Vehicle alarm.....	199
Vehicle battery	
battery monitoring system.....	222
connecting jump leads.....	220
warning symbols.....	220
Vehicle cleaning	
exterior.....	210
interior.....	212
parking sensors.....	115
Vehicle data recording.....	255
Vehicle recovery	
steering column lock.....	8
towing eyes.....	251
towing on four wheels.....	253
transporting the vehicle.....	253
Vehicle settings	
valet mode.....	74
Vehicle testing	
on a rolling road.....	201
Vehicle weights.....	260
Video	
dual view.....	162
dual view controls.....	162
inhibited display.....	161
rear media touch screen control.....	164
rear media use.....	166
Video media player	
controls.....	160
full screen view.....	161

Voice control.....	168
navigation POI categories.....	169
recognising your voice.....	169
training the system.....	169
tutorial.....	169
voicetags.....	169
Voice guidance	
navigation.....	183
Voice settings	
command list.....	73
operating guide.....	73
setting preferences.....	73
voicetags.....	73
voice training.....	73
Voicetags	
setting up voice shortcuts.....	169
Volume	
telephone.....	174

W

Wade sensing	
controls.....	137
Wading depth	
touch screen aid.....	137
Warning lamp	
electronic brake force distribution.....	111
emergency brake assist.....	111
Warning lamps.....	49, 51
ABS.....	51
ACC follow mode.....	51
adaptive front lighting system.....	51
AFS.....	51
airbags.....	42, 51
automatic speed limiter.....	51
battery charge.....	50
brake.....	49–50
critical warning message.....	49
cruise control.....	52
diesel glow plugs.....	50
DSC active.....	50
engine/transmission.....	50
engine temperature.....	49
external temperature.....	51
forward alert.....	52
gear shift warning lamp.....	52
HDC.....	52
headlamp high beam.....	51
high beam assist.....	52
indicators.....	52
intelligent stop/start (green).....	52
lamp test.....	49
low fuel.....	51
low oil pressure.....	49
low range selected.....	52
parking brake.....	50
rear fog lamps.....	51
seatbelt.....	50
side lights.....	52
trailer direction indicators.....	52
Warning symbols (battery).....	220
Washers	
fluid specification.....	218
fluid top up.....	218
operating.....	58
Washers (headlamps).....	59
Washing	
exterior paintwork.....	211
Water in fuel.....	196
Weights.....	260
Wheel changing	
important information.....	250
locking wheel nuts.....	247
recommended process.....	247
safety warnings.....	245
spare wheel.....	245
temporary spare wheel.....	246
tilt sensor.....	247
tool kit.....	245
use of spare tire.....	250
Wheel chocks use.....	246
Wheels and tyres	
age degradation.....	237
changing a tyre.....	240
checking the pressures after a repair.....	243
flat spots.....	237
full size replacements.....	240
Indian regulations.....	238

pressures.....	235
puncture repair.....	241
puncture repair safety.....	241
repair kit.....	241
repair kit use.....	242
repair procedure.....	242
replacements.....	236
snow chains.....	238
specifications.....	262
temporary use spare.....	240
TPMS.....	239
tyre care.....	234
tyre speed ratings.....	234
tyre wall markings.....	233
valves.....	236
wheel alignment.....	263
winter tyres.....	237
Windows	
operation.....	70
reset.....	210
sunroof	
reset.....	210
Winter park position	
front wipers.....	210
Winter tyres.....	237
Wipers	
operating.....	58
winter park position.....	60, 210
Wipers and washers	
fluid level.....	218
operating.....	58
rain sensor.....	59
speed-dependent mode.....	59

X

Xenon headlamps.....	206
----------------------	-----