


DAB RADIO CONTROLS



E154788



In the interest of safety, only operate or adjust the system when it is safe to do so.



Sustained exposure to high sound levels (greater than 85 decibels) can damage your hearing.

1. **DAB 1/2/3:** Touch to view and select a DAB band (**DAB 1, 2 or 3**). The radio will tune to the last used channel on that band. Touch again to close.
2. Display showing the current channel, the associated Ensemble and the relevant DAB radio text.
3. Seek down:
 - Short touch to seek a previous available channel.
 - Long touch to seek a previous available Ensemble. The first channel in the new Ensemble will be selected.
4. Channel information: Touch to view DAB text and channel information.
5. Seek up:

- Short touch to find the next available channel.
- Long touch to find the next available Ensemble. The first channel in the new Ensemble will be selected.

6. **Settings:** Touch to view the DAB Settings menu:
 - **Options:** To activate/deactivate **FM Traffic** and **Link DAB**, and to alter DAB country and format settings (with the vehicle stationary).
 - **Announcements:** Select an alarm announcement and up to 3 other announcement types (traffic, news etc.) from the list. The selected announcements will interrupt the current programme, when broadcast.
7. **Channel list:** Touch to view a list of available Ensembles and channels. The list can be sorted by **Ensemble, Channel, Subchannel** or by **Category**.