

- Only use the correct type of CD. The Navigation System will only work properly with the correct CDs.
- The Navigation System CD player does not play any other type of CDs (i.e. Audio CDs).
- Always store the CDs in their protective cases.
- The CDs are exclusively designed for use with the Navigation system and they are only readable by the Navigation System.

## **MAINTENANCE**

When cleaning the display do not use lighter fluid, methyl alcohol or other solvents, only use a damp cloth.

## **TROUBLESHOOTING**

There may be times when you suspect that your Navigation System is not functioning as you expect it to. Before calling for service please read the operating instructions and check the following list. You may find that an apparent malfunction can easily be rectified.

<b>SYMPTOMS</b>	<b>POSSIBLE CAUSE / REMEDY</b>
System does not start,, screen is dark	<ul style="list-style-type: none"><li>• Switch on the ignition.</li><li>• Ignition already switched on; system is in stand-by mode - Press the Rotary switch</li></ul>
After some time of normal operation, the system switches off.	<ul style="list-style-type: none"><li>• At extreme high or low temperatures the built-in protection circuit switches off the system automatically.</li><li>• Operation of the system is resumed as soon as the temperature returns to a normal level</li></ul>
System reacts very slowly or calculations take a long time.	<ul style="list-style-type: none"><li>• You are in a very densely digitized area. The navigation system has to read large amounts of data from the CD-ROM</li></ul>
Guidance option can not be selected from the Main Menu	<ul style="list-style-type: none"><li>• Make sure that you entered a destination address</li></ul>
System plans no route although a destination was entered.	<ul style="list-style-type: none"><li>• Car is not on a digitised road. Drive in the direction of a digitised (displayed) road.</li></ul>

SYMPTOMS	POSSIBLE CAUSE / REMEDY
No destination address input is possible by map.	<ul style="list-style-type: none"> <li>Destination input by map is only possible when the car speed does not exceed 30 km/h.</li> </ul>
Guidance advice not audible.	<ul style="list-style-type: none"> <li>Make sure that <b>Voice</b> is set to <b>on</b> in the <b>System Settings</b> menu (🔊 icon is not in the display).</li> <li>Make sure that the <b>Volume</b> is not set to minimum in the <b>System Settings</b> menu.</li> </ul>
Some of the items shown in the instruction manual are not visible in the status line.	<ul style="list-style-type: none"> <li>Activate/deactivate the desired items with options <b>Status line left</b> and <b>Status line right</b> in the <b>System Settings</b> menu</li> </ul>
Only <b>Stand-by</b> can be selected in the <b>Main Menu</b> after switching on the ignition	<ul style="list-style-type: none"> <li>Wait a few seconds until the system has booted (options appear in highlighted letters).</li> </ul>
Storing address is not possible in map display mode.	<ul style="list-style-type: none"> <li>Decrease map scale value to 100 m, 200 m, 500 m or 1 km</li> </ul>
Colour of the satellite icon on the GPS logo is constantly red.	<ul style="list-style-type: none"> <li>Make sure any objects do not cover the GPS aerial.</li> <li>Drive into the clear, if you are in a garage, a car park or a tunnel.</li> </ul>
Display shows NO CD or WRONG CD	<ul style="list-style-type: none"> <li>Make sure that an appropriate CD is inserted with the label side facing up in the CD player</li> </ul>
CD is ejected unintentionally.	<ul style="list-style-type: none"> <li>The CD might be dirty.</li> <li>Try to clean the CD with a special CD cleaning fluid.</li> </ul>
Current time in the status line is wrong.	<ul style="list-style-type: none"> <li>Adjust the time zone in the <b>Systems Settings</b> menu, option Date / Clock.</li> </ul>
Not possible to store address in the address book.	<ul style="list-style-type: none"> <li>Address book is full.</li> <li>Delete one or more entries no longer required</li> </ul>

<b>SYMPTOMS</b>	<b>POSSIBLE CAUSE / REMEDY</b>
Entered relocation junction is not accepted during car position input.	<ul style="list-style-type: none"><li>• Not all junctions, you can enter with the typewriter are suitable for relocation.</li><li>• Select a junction displayed in the list.</li></ul>
Guidance is not precise	<ul style="list-style-type: none"><li>• An inaccuracy of max. 30 m is in the limit. If you frequently discover greater inaccuracy, contact an authorised service</li></ul>
Displayed car position does not correspond with actual car position.	<ul style="list-style-type: none"><li>• Bad GPS reception for a long periods. When sufficient GPS reception is resumed the position is connected automatically.</li><li>• If necessary wait a few minutes.</li></ul>
Guidance advice does not correspond with actual traffic situation.	<ul style="list-style-type: none"><li>• It is possible that the car position calculated by the navigation system is wrong at the moment.</li></ul>
	<ul style="list-style-type: none"><li>• The routing may be changed and does not correspond with the information stored on the CD.</li></ul>

If you can't find a solution to any problem you may encounter, contact an authorised Land Rover dealer.